



Welcome to Nexus Flat Rate Manual. This manual is designed and developed by Nexus RV with the following goals in mind.

- Easy to use
- Detailed without being cumbersome
- Adaptable to PC Applications
- Fair and accurate time allowances
- Easy to update
- Accurately Coded
- Allow feedback to Nexus

This manual also presents your dealership with an excellent tool in which to measure and evaluate your service departments productivity and efficiency. Nexus strongly recommends that you accurately clock all repairs on a claim in order to calculate these two important measurements. **Clocking is required for any "Straight Time" claimed.**

Not all repairs that are listed in this manual are warranted by Nexus RV. Our warranty statements can be found on the following pages for your review. You will be responsible for submitting claims that fall under the terms of our warranties.

Many operations cannot be started until the dealer has Prior Approval. Such operations marked with an "X" in the "Approval Required" column.

The times listed include access, diagnosis, removal and re-installation, set-up and testing unless otherwise noted. Should you feel a time allowance is inadequate or the manual lacks a particular code for repair, please complete the "Flat Rate Review Request" form located in the back of this section and return to Nexus RV.

The labor allowances in this manual are subject to change by Nexus RV. Changes would typically be based on the improved methods, techniques, or advances in the recreational vehicle industry.

Nexus RV's Policy and Procedures Manual contains warranty claim submission instructions.



Flat Rate Review Request

Dealer: _____

Dealer # _____

Contact: _____

Date: _____

Nature of Request:

_____ Review of existing operation

_____ Adding an operation

Section No: _____

Page No: _____

Operation: _____

Unit Serial Number: _____

Why is this change needed (Be Specific)

How many times has your dealership completed this repair? _____

What is the average time for the completion of the repair? _____

RETURN TO:

Nexus RV
2994 Paul Drive
Elkhart, IN 46514



Definition of Terms

Claim Form – Claim submitted electronically via the Nexus website.

Condition Code – A number assigned to identify the cause of a needed repair. Each repair is required to have a condition code.

Door Side (DS) – Refers to the entry door side of a unit. Also referred to as passenger side or curb side.

Drop Pressure Test – A LP system test utilizing a manometer which verifies the system is not leaking. This test is required after certain repairs have been completed to the LP system.

Water Pressure Test - A water system test in which air is put into the fresh water system to detect the presence of a leak. This test is required after certain repairs have been completed to the water system.

Off Door Side – Refers to the off-entry door side of a unit. Also referred to as driver's side or roadside.

Operation – A description of the type of repair performed to a component.

Operation Number – a five (5) digit code assigned to represent the labor operation.

Prior Approval – Authorization in the form of a number, to perform a repair before the repair is started or the parts are ordered.

R & R – Remove and replace component.

R & I – Remove and re-install a component.

Remove, Seal, Reinstall – To be used when the component seal has failed. Remove the component, clean old sealant(s) off, install new sealant(s), and reinstall the component.

Must Return Part – A part which has been replaced during a warranty repair that must be returned to Nexus. It must be returned with the warranty claim.



Definition of Terms (Continued)

Straight Time (ST) – (ST) is any warranty repair in which an operation cannot be found to match the description of the repair. (ST) can also be requested under the following circumstances:

- The repair required additional time due to complications relating to component location, poor accessibility, corrosion, damage, etc.
- Repair completion involved additional procedures that do not have flat rate codes.
- Technician comments support the ST claimed by detailing exactly why additional time was needed.

All repairs involving straight time (ST) must be supported by technician clock time for the total repair. Any repair times that include Straight time where the total repair time claimed exceeds 2.0 hrs. requires prior approval.

Time- The labor allowance, in tenths of an hour, which can be claimed for a warranty repair.



Using NeXus RV's Flat Rate Manual

FEATURES TO HELP YOU

- **Divided into nine (9) class code sections.** Labor operations are grouped in sections that match those found in NeXus RV's Parts Catalog.
- **Indexing.** The beginning of each section has an index of the components found within the section.
- **Must Return Parts List.** Located under the tab "Parts replaced under NeXus RV's Warranty". Also noted by operation number in each section.
- **Prior Approval Authorization Request.** Must be submitted electronically.
- **Lamination "Quick Reference" Card.** Contains listings of Program Codes, Condition Codes and a summarized version of the Prior Approval Required List.



Using NeXus's Flat Rate Manual

Approval Required

After an operation has been found, determine if it requires Prior Approval. This is indicated with an "X" in the "Approval Required" column. Approval can be obtained by submitting the Prior Authorization Request electronically.

Operation Number

The 5 digit code assigned to represent an operation. The first 4 digits will be numerical and the last digit will be an alpha character. Straight time is indicated with (ST).

Time

This is the labor allowance for an operation performed. All times listed are the maximum allowed for the operation unless otherwise noted. (ST) indicates a straight time operation.

Must Return Part

This column indicates whether the warranty part must be returned to Nexus. This is indicated with an "X" in the "Return Parts" column. Please note that when a part is returned to Nexus for warranty consideration, the warranty claim must accompany that part. **DO NOT** send the claim separately by mail.

Straight Time (ST)

(ST) is any warranty repair in which an operation cannot be found to match the description of repair. (ST) can also be requested under the following circumstances:

- The repair required additional time due to complications relating to component location, poor accessibility, corrosion, damage, etc.
- Repair completion involved additional procedures that do not have flat rate codes.
- Technician comments support the ST claimed by detailing exactly why additional time was needed.

All repairs involving straight time (ST) **must** be supported by technician clock time for the total repair. Any repair times that include straight time where the **total** repair time claimed exceeds 2.0 hrs. requires prior approval.



PRIOR APPROVAL REQUIRED LIST

CHASSIS/FRAME

A-Frame/Coupler
Air bag
Axle/Axel Tube
Bumper
Cruise Control
Firewall/Dog House Frame
Frame/Hitch
Fuel Tank
Jacks
Mor/Ryde
Pin Box
Tailpipe
Tires/Wheels
Vacuum Pump

EXTERIOR

Access Door-Bus Type
Compartment-Plastic
Driver's Door
Driver's Door Panel
Entry Door-Bus Type
Fiberglass Caps/Bumper
Grill
Hood
Living Hinge
Metal Siding
Painting
Patio Door
Step
Stone Guard
Structure Repairs
Up & Angles
Windows
Windshield

INTERIOR

Ceiling Fabric/Structure
Corian Countertop
Dash
Engine Cover
Floor Coverings
Floor Repair
Kitchen Base
Kitchen Countertop
Slideout Repairs
Slideout-Cylinder
Slideout-Pump/Reservoir
Slideout-Ram
Swingdown Bunk



PRIOR APPROVAL REQUIRED LIST

SOFT GOODS

Arm Rests
Blinds
Covers
Foam
Frames
Furniture
Mattresses
Shades
Tent
Treatments
Vinyl

WATER SYSTEM

Shower Enclosure
Toilet

LP GAS

Tank

ELECTRICAL

Battery
Ceiling Fan
Dash Overhead
Instrument Cluster
Monitor Panel
Power Center
Power Inverter

APPLIANCES

Appliances
Remote Control
Water Heater Tank
Television

ACCESSORIES

Awning Fabric
Awning Tube
Awnings
Fuel Tank
Generator Controller
Radios
Rearview TV System
Running Boards
Satellite Dish
Satellite Receiver
TV Antenna
VCR/VCP



Parts Replaced Under NeXus Warranty

Certain parts replaced under NeXus warranty are considered “Must Return Parts”. It is indicated with an ‘X’ in the “Return Part” column. We have also provided a “Must Return Parts” List in this section for your convenience. Those parts which are **not** “Must Return Parts” are not required to be held and can be scrapped.

NOTE: Must Return Parts are established by our suppliers and are necessary for Vendor recovery.

NOTE: Canadian dealers are required to return parts unless notified to do so.

Please follow these steps when sending a “Must Return Part” to NeXus:

1. Fill out a “Parts Return Tag” and attach it to the part. These are available No-Charge from NeXus. See the Policy Procedures Manual for instructions on filing out the “Part Return Tag”.
2. Package the part and “Parts Return Tag”. It is not necessary to include a copy of the claims.
3. Properly package the part for shipment. Be sure it is protected from possible shipping damage. Parts that come in improperly packaged will be denied.
4. **Pre-pay the shipping** and return to:

NEXUS RV

Attention: Warranty Department

2994 Paul Dr.

Elkhart, IN 46514

Note: Shipping warranty parts is reimbursable on the warranty claim. See the Policy and Procedure Manual for instructions or contact your Service Manager for assistance.

NeXus RV can provide Parts Return Tags, pre-addressed Shipping Labels at *no charge*, upon request. Simply contact your Service Manager for supplies.



Must Return Parts List

Chassis & Frame

Dash A/C Heater

Blower Box	Expansion Valve
Blower Motor	Freon Coil
Blower Wheels	Heater Coil
Circuit Board (Printed)	Receiver Drier
Cold Control	Return Grille
Condenser Coil	Switches (Blower, Pressure, A/C)
Condenser Fan	Vacuum Harness
Control Cable	Vacuum Motor
Control Panel	Vacuum Pump
Control Panel Face Plate	Vacuum Tank
Evaporator/Heater Coil	Water Valve
	Wire Harness-Motor

Horns

Horn (Air)	Reservoir
Horn (Electric)	Solenoid
Compressor	Switch
Line	

Tire & Wheel

Wheel Cover (Hub Cap)	Wheel Liner
Valve Extenders	Center Cap
Lug Nut Covers	

Vacuum Pump

Vacuum Pump

Windshield Washer & Wiper

Connecting Link	Switch (Dash Mounted)
Wiper Blade	Wiper Delay/Relay
Wiper Arm	Fluid Bottle (Include Pump/Motor)

Exterior

Horns

All Horns

Attachments-Sidewall

Cable/Phone Jacks	Mirror Heads
Mirrors	Entertainment Center (outside)
Directional switch	

Bus Type Entry Door

Bus Type Screen Door Latch	Bus Type Keyless Entry Lock
Bus Type Lock Assembly	

Grill

Louvered Type Grill



Must Return Parts List

Exterior (Continued)

Hood	Hood Release Cable	Hood Hinge (single & dual)
Step-Entry Door	Regulator/Control Module	Electric Step

Interior Cabinetry & Hardware

Clock	Wall clock	
Dash	Sun Visor (Electric)	
Carpet	Return Only a 24"x24" section	
Seat Belts	All Seat Belts	
Slide-Out System	(Dewald)	Check Valve Gear Hydraulic Hose Motor Pump and Reservoir
		Pump Solenoid Ram Relay Switch
	(HWH)	Check Valve Cylinder Assembly Rack Sensing Hydraulic Hose
		Pump Synchronizing Cylinder Cylinder Assembly (Single & Double) Tube Kit
	(Lippert Gear Drive System)	All Parts Must Be Returned

Soft Goods

Furniture	(Chair)	Barrel/Lounge Chair Pedestal Base Covers Wall Hugger Chair	Frame Freestanding/Metal Chair Swivel Rocker Chair Foam
	(Cushions)	Cabover Cushion Covers	Dinette Cushions Foam Insert
	(Pilot Seat)	All seats Arm Rest	Frames Motor



Must Return Parts List

Soft Goods (Continued)

(Pilot Seat Cont.)	Covers Electric Power Mechanism Foot Rest Motor	Foam Seat Belts
(Sofa)	Sofa Metal Frame Jackknife Arm (pre-upholstered) Seat or Back Assembly Sofa Hide-A-Bed Covers Mattress Air Mattress Pump	Foam Kickboard Sofa Hide-A-Bed Frame Sofa Hide-A-Bed Air Mattress Bladder

Treatments

(Bedspread)	Bedspread	
(Curtains/Draperies)	All Curtains/ Draperies	Windshield Privacy Curtains
(Mattress)	Bunk Bed	Bunk Bed Cover
(Shades)	All Shades Roller Tube	Pleated Shades Sunscreen Shades
(Vertical Blind)	Vertical Blind	

Water System

Faucets	All Faucets	Spray Attachments
----------------	-------------	-------------------

Holding Tanks	All Holding Tanks (Return the defective portion only) Mounting	Undermounting
----------------------	---	---------------

Outside Shower	Outside Shower
-----------------------	----------------

Tubs/Surrounds/Shower Pans	All Tubs/Surrounds/Shower Pans (Return the defective portion only)
-----------------------------------	---

Toilets	All Toilets
----------------	-------------

Water Pump	All Water Pump
-------------------	----------------

Water Purifier	Water Purifier
-----------------------	----------------



Must Return Parts List

LP Gas System

Leak Detector

Leak Detector (Electronic)

Regulator

Regulator

Tank

Tank
80% Stop Fill Valve
80% Stop Fill Valve Gasket
20% Bleeder Valve

On/Off Valve
Sending Unit
Sight Gauge

Electrical

Battery/ Battery Components

Battery Disconnect Panel

Battery Disconnect Solenoid

Ceiling Fan

Ceiling Fan

Dash/Cockpit Components

Cornering Light Module
Overhead Panel – Destiny

Tv Lock-Out Relay
Fuel Gauge – Generator

Defroster Fan

Defroster Fan

Entertainment Center (Outside)

Entertainment Center

Lights (Exterior)

Headlight Pod Assembly
Brake Taillight Pod Assembly

Spot Light
Remote Control

(Interior)

Combination 12V/110V
Decorator (Ceiling)
Table Lamp 12V/110V
Wall lamp 12V/110 V

Strip Light
Strip Light Inverter
Fluorescent
Hanging Light

Monitor Panel

All Parts are Must Return

Power Center/Power Inverter

Power Center
Power Converter
Charger Section
Distribution Panel

Transfer Switch
Power Inverter
Converter/Charger Module

Receptacles

110V-GFI

Shore Line Cord

All Parts are Must Return

Relays

TV Lock-Out Relay



Must Return Parts List

Electrical (Cont.)

Solenoid

Dual Battery/Emergency Start Slide-Out System

Switches

Exterior Mirror Directional Dimmer Switch
 Generator Remote Start Electric Window
 Windshield Washer & Wiper Monitor Panel
 Air Conditioner Selector Transfer Switch (Power Center Mount)
 Transfer Switch (Non-Power Center Mount)

Appliances

Air Conditioner- Roof

(Duo-Therm/Dometic)

Capacitor -Run Condenser – Motor
 Capacitor -Start Relay Module Board
 Compressor Thermostat/Wall Thermostat
 Filter Drier

Coffee Maker

Complete Assembly

Furnaces

(Suburban)

Module Board Blower Motor
 Power Converter Gas Valve
 Relay Thermostat/Wall

Ice Maker

Complete Assembly

Microwave Oven

Complete Assembly

Oven/Range

All Parts (Except Range Top)

Refrigerator

(Dometic)

Safety Gas Valve Solenoid Valve
 Heating Element Re-Igniter
 Module Boards Thermo Couple
 Thermostat (Thermister) Piezo Ignition
 Upper PC Board Climate Control Switch
 Door switch

(With-ICE Maker)

Compressor Harvest Mechanism
 Condenser Motor On/Off Switch
 Current Relay Water Solenoid Valve
 Filter Dryer

Refer/Freezer Compartment Mount

All Parts Are Must Return



Must Return Parts List

Appliances (Cont.)

Remote Control

Remote Control

Television

Complete Assembly

Vacuum Cleaner

Complete Assembly

Water Heater (Atwood)

Relief Valve
Solenoid Valve
Inner Tank
Thermostat & ECO
Thermostat – 110V & 120V
Thermostat – Gas

Circuit Board
Control Valve (Pilot Models)
Fuse Link (Thermal Cut-off)
Heating Element
Spark & Probe assembly
Pilot Assembly

(Suburban)

Electric Thermostat
Module Board
Relief Valve
Thermostat ECO

Heating Element
Gas Control Valve (Electronic)
Gas Control Valve (pilot models)

Accessories

Awnings

Complete Assembly
Control Box (Electric)
Remote Control
Wind Sensor

Fabric
Motor
Torsion Assembly (Electric)
Spring Assembly

CO Detector

Complete Assembly

Fire Place

Complete Assembly

Generator

Sending Unit
Fuel Tank

Remote Start Switch
Generator Controller

Grill

Complete Assembly

Radios

All Parts are Must Return

Rearview Television System

Camera (Rear & Side)

Monitor

Smoke Detector

Complete Assembly



Must Return Parts List

Accessories (Cont.)

TV Antenna

Antenna Head	Complete Assembly
Coax Receptacle	Power Supply/Booster

VCP/VCR

Complete Assembly

Video/TV Switch Box

Complete Assembly



Serial Number Requirement List

When submitting a NeXus warranty claim for component repairs, the model and serial number of certain components **Must Be** recorded in the appropriate area of the warranty claim.

The following is a list of components with the location of the model and serial numbers. Any components on this list **Must Have** the model and serial number recorded on the warranty claim in order to be considered for warranty reimbursement.

Air Conditioners

Roof- Coleman	Label located on the bottom of the base pan.
Roof -Duotherm	Label located on the bottom of the base pan.
Dash	Label located on outside casing under hood.

Awnings

A&E Arm	Label located on upper main arm.
A&E Tube	Label located on tube – forward end under fabric.
Carefree	Label located on bottom of fabric when awning is rolled out.

Axle

Label located on axle tubing.

Back Up Monitor

Label located on back of the casing.

Furnaces

Hydroflame	Label located behind exterior door on blower housing.
Suburban	Label located behind exterior door on blower housing.

Ice Maker

Label located on back inside wall.

Microwave

Label located on left inside wall.

Radio

Label located on the top or bottom housing.

Refrigerator

Dometic	Label plate located to the to the left or on the bottom after the interior door is open.
Norcold	Label plate located on bottom plate after the interior door is open.

Stove/Oven

Label located under stove top to the back, right.

Television

Label located on the back of TV.

VCP/VCR

Label located on back of casing.



Serial Number Requirement List Continued

Washer/ Dryer

Label located on the door or door frame.

Water Heater

Label located behind exterior vent to the right.



CHASSIS & FRAME

ABOUT THIS SECTION:

ALL LABOR ALLOWANCE INCLUDE ACCESS, DIAGNOSIS, REMOVE AND REINSTALL OF COMPONENTS, SET-UP, AND TESTING UNLESS OTHERWISE INDICATED.

COMPONENT

- BUMPERS
- DASH A/C- HEATER ASSEMBLY
- EXHAUST SYSTEM
- FIREWALL
- FRAME COMPONENTS
- FUEL SYSTEM
- HORNS
- MUD FLAP
- TIRE & WHEEL
- WINDSHILD WASHER & WIPER



CHASSIS & FRAME

OPERATION		APPROVAL		MODEL#, SERIAL #	
OPERATION	NUMBER	TIME	REQUIRED	RETURN PART	REQUIRED
<u>BUMPERS</u>					
PAINTED BUMPER					
R&R	1060A	1.0	X		
R&I	1060B	0.5			
PAINT IN PLACE	1060P	0.3	X		PICTURE
SQUARE STORAGE TYPE					
BUMPER WELD-ON					
R&R	1061A	1.5	X		
PAINT	1061P	0.5	X		
WELD (pre-extension)	1061W	0.3	X		
PLUGS					
INSTALL (1or2)	1063I	0.1			
BUMPER BOLT-ON					
R&R	1064A	0.5	X		
PAINT	1064P	0.5	X		
MISCELLANEOUS					
BUMPER BOLT					
R&R	1080A	0.1			
NO SKID TAPE (bumper or step)					
R&R	2201A	0.2			



CHASSIS & FRAME

OPERATION		APPROVAL		MODEL#, SERIAL #	
OPERATION	NUMBER	TIME	REQUIRED	RETURN PART	REQUIRED

DASH A/C-HEATER ASSEMBLY

NOTE: REPLACEMENT PARTS USED TO REPAIR EVANS AIR CONDITIONER/HERTER ASSEMBLIES MUST BE AUTHETBIC EVANS PARTS. USE OF NON-EVANS PARTS IS NOT ALLOWED AND MAY RESULT IN DENIAL OF CLAIM.

EVANS

BLOWER BOX					
R&R	1469A	1.0	X		X
SEAL	1469S	0.2			
BLOWER MOTOR					
R&R	1457A	1.0	X		X
BLOWER WHEELS					
R&R	1465A	1.0	X		X
COLD CONTROL					
R&R	1458A	0.3	X		X
CONDENSOR COIL					
R&R	1456A	2.0	X		X
CONDENSOR FAN					
R&R	1472A	0.5	X		X
CONTROL CABLE					
R&R	1471A	0.8	X		X
ADJUST	1471J	0.2			
CONTROL PANEL					
R&R	1470A	0.5	X		X
CONTROL PANEL FACE PLATE					
R&R	1466A	0.5	X		X
CONTROL PANEL VACUUM HARNESS					
R&R	1467A	0.5	X		X
CONTROL PANEL WIRE HARNESS					
R&R	1460A	0.5	X		X
DASH VENT- LOUVERED					
R&R	1138A	0.3			
R&I	1138B	0.2			
DEFROST VENT					
R&R	1139A	0.2			
R&I	1139B	0.2			
DRAIN HOSE					
REPAIR	1140C	0.2			
EVACUATE,RECHARGE,TEST	1148O	1.0			
EVAPORATOR COIL					
R&R	1451A	2.0	X		X
EXPANSION VALVE					
R&R	1450A	1.4	X		X

**CHASSIS & FRAME**

OPERATION		APPROVAL		MODEL#, SERIAL #	
OPERATION	NUMBER	TIME	REQUIRED	RETURN PART	REQUIRED

DASH A/C-HEATER ASSEMBLY

NOTE: REPLACEMENT PARTS USED TO REPAIR EVANS AIR CONDITIONER/HEATER ASSEMBLIES MUST BE AUTHENTIC EVANS PARTS. USE OF NON-EVANS PARTS IS NOT ALLOWED AND MAY RESULT IN DENIAL OF CLAIM.

EVANS (CONT.)

FREON HOSE					
R&R	1459A	1.3	X		X
HEATER COIL					
R&R	1455A	1.0	X		X
HEATER HOSE					
R&R	1468C	0.5			
RECEIVER DRIER					
R&R	1453A	1.3	X		X
RETURN GRILL					
R&R	1464A	0.2			X
VENT HOSE (DUCT)					
R&R	1153A	0.4			
RESECURE	1153R	0.3			
SWITCHES, (Blower, Pressure & A/C)					
R&R	1452A	0.3	X		X
VACUUM LEAK					
L&R	1150L	0.3			
VACUUM MOTOR (FRESH AIR/RECIRCULATION DOOR)					
R&R	1461A	0.3	X		X
VACUUM MOTOR (AIR DISTRIBUTION BOX)					
R&R	1462A	1.0	X		X
WATER VALVE					
R&R	1454A	0.5	X		X
WIRE HARNESS-MOTOR					
R&R	1463A	0.8	X		X
VACUUM TANK					
R&R	1473A	1.0	X		X
CONTROL KNOB					
R&R	1474A	0.1	X		
VACUUM PUMP					
R&R	1475A	0.8	X		X
PRINTED CIRCUIT BOARD					
R&R	1476A	0.5	X		X

EXHAUST SYSTEM

HEAT SHIELD – SEE FRAME COMPONENTS

TAIL PIPE					
R&R	1170A	1.0	X		
RESECURE	1170R	0.2			



CHASSIS & FRAME

OPERATION		APPROVAL		MODEL#, SERIAL #	
OPERATION	NUMBER	TIME	REQUIRED	RETURN PART	REQUIRED
<u>EXHAUST SYSTEM (CONT.)</u>					
TAIL PIPE EXTENSION R&R	1171A	0.2			
TAIL PIPE HANGER R&R	1172A	0.2			
<u>FIREWALL</u>					
NOTE: TEST DRIVE ALLOWED ONCE PER REPAIR OF A FIREWALL AIR LEAK.					
TEST DRIVE	1180T	0.5			
AIR LEAK SEAL	1180S	0.2			
<u>FRAME COMPONENTS</u>					
BATTERY TRAY – STATIONARY R&R	1201A	0.4			
WELD	1201W	0.3			
PAINT TOUCH -UP	1201X	0.3			
BATTERY HOLD DOWNS R&R	1216A	0.2			
BRACKET R&R	1202A	0.3			
INSTALL	1202I	0.5			
FABRICATE	1202Q	0.4			
WELD	1202W	0.3			
BUMPER EXTENSION – RAIL TO BUMPER WELD	1203W	0.3			
CROSS MEMBER R&R	1204A	1.0			
INSTALL	1204I	0.5			
WELD	1204W	0.5			
FIREWALL / DOGHOUSE FRAME WELD	1217W	ST	X		
FRAME EXTENSION R&R	1205A	1.0			
WELD (RAIL)	1205W	0.3			
HEAT SHEILD INSTALL	1207I	0.5			
FABRICATE	1207Q	0.5			
WELD	1207W	0.3			
HITCH R&R	1219A	0.5	X		X
MUD FLAP T-BAR R&R	1209A	0.2			



CHASSIS & FRAME

OPERATION	OPERATION		APPROVAL		MODEL#, SERIAL #	
	NUMBER	TIME	REQUIRED	RETURN PART	REQUIRED	
<u>FRAME COMPONENTS (CONT.)</u>						
OUTRIGGER						
INSTALL	1210I	0.4				
WELD OUTRIGGER	1210W	0.3				
SKID GUARD						
WELD	1213W	0.3				
SPARE TIRE CARRIER (BUMPER MOUNT)						
R&R	1214A	0.2				
R&I	1214B	0.2				
REPAIR	1214C	0.3				
WELD	1214W	0.3				
STEP – DRIVER'S DOOR						
WELD	1215W	0.3				
SPARE TIRE HOIST						
R&R	1315A	0.5				
<u>FUEL SYSTEM</u>						
FILL TUBE						
R&R	1224A	0.5				
R&I	1224B	0.5				
RELOCATE	1224F	0.5				
RESECURE	1224R	0.2				
FILL TUBE VENT						
R&R	1225A	0.5				
R&I	1225B	0.5				
RELOCATE	1225F	0.5				
RESECURE	1225R	0.2				
FUEL LINE						
R&R	1229A	0.3				
R&I	1229B	0.3				
LEAK -LOCATE & REPAIR	1230L	0.2				
<u>HORNS</u>						
HORN – ELECTRIC -ROOF						
R&R	2078A	0.3			X	
HORN AIR						
R&R	2060A	0.2			X	
COMPRESSOR						
R&R	1261A	0.2			X	
LINE						
R&R	1262A	0.5			X	
RESERVIOR						
R&R	1263A	0.2			X	
SOLENIOD						
R&R	1264A	0.3			X	
SWITCH						
R&R	7090A	0.2			X	



CHASSIS & FRAME

OPERATION	OPERATION		APPROVAL		MODEL#, SERIAL #	
	NUMBER	TIME	REQUIRED	RETURN PART	REQUIRED	
<u>MUD FLAP</u>						
MUD FLAP (WHEEL)						
INSTALL	1310I	0.3				
R&R	1310A	0.2				
MUD FLAP T-BAR						
R&R	1209A	0.2				
MUD FLAP (REAR)						
R&R	1311A	0.5				
<u>TIRE & WHEEL</u>						
SPARE TIRE AND WHEEL						
R&R	1384A	0.1	X		X	
WHEEL COVER (HUB CAP)						
R&R (1-2pcs.)	1385A	0.1			X	
WHEEL COVER CLIP						
R&R	1386A	0.1				
WHEEL COVER RETAINER ASSEMBLY						
R&R	1387A	0.3				
R&I	1387B	0.3				
WHEEL LINER – STAINLESS STEEL						
R&R	1388A	0.2			X	
WHEEL CENTER CAP						
R&R	1389A	0.3			X	
LUG NUT COVERS						
R&R (PER UNIT)	1393A	0.1			X	
VALVE EXTENDERS						
R&R	1394A	0.2			X	
R&I	1394B	0.2				
WHEEL CENTER CAP (SNAP-ON) (PER UNIT)						
REPLACE	1397A	0.1				
DECAL (WHEEL LINER/COVER)						
R&R (PER UNIT)	1398A	0.1				
<u>WINDSHIELD WASHER&WIPER</u>						
NOTE: LABOR ALLOWANCES DO NOT INCLUDE ACCESS TIME FOR OVER-HEAD INSTALLATIONS.						
FLUID BOTTLE						
R&R	1390A	0.2			X	
R&I	1390B	0.2				
HOSE						
R&R	1391A	0.2				
RESECURE	1391R	0.1				
NOZZLE						
R&R	1392A	0.2				
R&I	1392B	0.2				
WIPER ARM						
R&R	1400A	0.2			X	
R&I	1400B	0.2				
ADJUSTMENT OF WIPER ANGLE	1400J	0.2				



CHASSIS & FRAME

OPERATION		APPROVAL		MODEL#, SERIAL #	
OPERATION	NUMBER	TIME	REQUIRED	RETURN PART	REQUIRED
<u>WINDSHEILD WASHER & WIPER (CONT.)</u>					
WIPER BLADE					
R&R	1401A	0.2		X	
MOTOR/TRANSMISSION ASSEMBLY					
R&R	1402A	0.4		X	
R&I	1402B	0.4			
WIPER DELAY/RELAY					
R&R	1403A	0.2		X	
SWITCH – DASH MOUNTED					
R&R	7125A	0.2		X	
R&I	7125B	0.2			
PIVOT SHAFT					
R&R	1405A	0.2		X	
CONNECTING LINK					
R&R	1406A	0.2		X	
ACORN NUT					
R&R	1407A	0.1			



ABOUT THIS SECTION:

ALL LABOR ALLOWANCES INCLUDE ACCESS, DIAGNOSIS, REMOVE AND REINSTALL OF COMPONENTS, SET – UP, AND TESTING UNLESS OTHERWISE NOTED.

COMPONENTS

- ACCESS DOOR WITH FRAME
- ACCESS DOOR – BUS STYLE
- ANTENNA'S
- ATTACHMENTS -ROOF
- ATTACHMENTS – EXTERIOR SIDEWALL
- COMPARTMENT
- DECAL
- DÉCOR TAPE
- ENTRANCE DOOR & FRAME ASSEMBLY
- BUS TYPE ENTRY DOOR
- FIBERGLASS/ABS ATTACHMENTS
- GRILL
- HOOD
- METAL
- MOLDINGS
- PAINT STRIPE
- STEP-ENTRY DOOR
- STRUCTURE (FLOOR, ROOF, WALLS)
- UNDERBELLY MATERIAL
- WHEEL WELL
- WINDOWS
- WINDOW COMPONENTS
- WINDSHIELDS



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>ACCESS DOORS WITH FRAME</u>					
BAGGAGE COMPARTMENT					
R&R	2010A	0.5			
R&I	2010B	0.5			
REMOVE, SEAL, REINSTALL	2010D	0.5			
BATTERY COMPARTMENT					
R&R	2011A	0.4			
R&I	2011B	0.4			
REMOVE, SEAL, REINSTALL	2011D	0.4			
ENGINE COMPARTMENT					
R&R (REAR DIESEL)	2370A	0.5			
R&I (REAR DIESEL)	2370B	0.5			
ENGINE COMPARTMENT HINGE					
R&R (REAR DIESEL)	2490A	0.5			
GARAGE COMPARTMENT					
R&R	2460A	1.0			
R&I	2460B	0.7			
REMOVE, SEAL, REINSTALL	2460D	0.7			
GENERATOR COMPARTMENT					
R&R	2013A	0.4			
R&I	2013B	0.4			
REPAIR	2013C	0.3			
LP COMPARTMENT					
R&R	2014A	0.3			
R&I	2014B	0.3			
REFRIGERATOR COMPARTMENT (COMPLETE)					
R&R	2016A	0.5			
R&I	2016B	0.5			
REMOVE, SEAL, REINSTALL	2016D	0.5			
CAP SEAL	2016S	0.1			
DOOR HOLDER (WALL MOUNT)					
R&R (1-2 pcs.)	20478A	0.1			
LOCK KEY					
R&R	2012A	0.1			
ADJUST	2012J	0.1			
LOCK – THUMB					
R&R	2022A	0.1			
ADJUST	2022J	0.1			
SEAL – FOAM					
R&R	2029A	0.3			
SCREW COVER					
R&R	2023A	0.1			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>ACCESS DOORS-BUS STYLE</u>					
BULB SEAL					
R&R (PER COMPARTMENT)	2356A	0.2			
C-CHANNEL					
R&R	2357A	0.2			
R&I	2357B	0.2			
DOOR					
R&R	2350A	1.0	X		
R&I	2350B	0.2			
DOOR HOLDER- WALL MOUNT					
R&R (1-2 pcs.)	2048A	0.1			
FIXED PANEL					
R&R	2351A	0.8	X		
R&I	2351B	0.6			
GAS STRUT					
R&R	2025A	0.1			
R&I	2025B	0.1			
BRACKET					
R&R	2359A	0.1			
R&I	2359B	0.1			
L-BRACKET (FIXED PANEL)					
R&R	2355A	0.1			
ADJUST	2355J	0.1			
LOCK – CIRCLE KEY					
R&R	2364A	0.2			
ADJUST	2364J	0.1			
LOCK – SLAM KEY					
R&R	2027A	0.3			
R&I	2027B	0.3			
LOCK – PADDLE LATCH					
R&R	2026A	0.3			
R&I	2026B	0.3			
ADJUST (LINKAGE)	2026J	0.2			
LOCK – STRIKER (PER DOOR)					
ADJUST	2372J	0.2			
LOWER EXTRUSION					
R&R	2358A	0.2			
R&I	2358B	0.1			
<u>ANTENNA'S</u>					
ANTENNA- TV/ OTHER (SEE ACCESSORIES)					
<u>ATTACHMENTS-ROOF</u>					
LADDER					
R&R (INCLUDES SEAL)	2051A	0.5			
R&I (INCLUDES SEAL)	2051B	0.5			
REMOVE, SEAL, REINSTALL	2051D	0.5			
CAP SEAL	2051S	0.3			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>ATTACHMENTS- ROOF (CONT.)</u>					
LUGGAGE RACK					
R&R	2054A	0.5			
R&I	2054B	0.5			
REMOVE, SEAL, REINSTALL	2054D	0.5			
CAP SEAL	2054S	0.3			
HORN – AIR					
R&R	1260A	0.3		X	
R&I	1260B	0.3			
HORN -LINE					
R&R	1262A	0.5			
PLUMBING VENT					
R&R	2053A	0.2			
R&I	2053B	0.2			
REMOVE, SEAL, REINSTALL	2053D	0.2			
CAP SEAL	20532S	0.1			
RADIO ANTENNA					
REPLACE	7292A	0.4			
R&I	7292B	0.4			
CAP SEAL	7292S	0.1			
ROOF VENT – REFRIGERATOR					
R&R	2076A	0.3			
R&I	2076B	0.3			
CAP SEAL	2076S	0.2			
ROOF VENT – NON- POWERED					
R&R (INCLUDES SEAL)	2056A	0.4			
R&I (INCLUDES SEAL)	2056B	0.4			
REMOVE, SEAL, REINSTALL	2056D	0.4			
CAP SEAL	2056S	0.2			
R&R (COVER)	2057A	0.2			
R&R (CRANK HANDLE)	2058A	0.1			
R&R (CRANK MECHANISM)	2059A	0.2			
R&R (GARNISH)	2060A	0.1			
R&R (SCREEN)	2061A	0.1			
ROOF VENT- POWERED					
R&R (INCLUDES SEAL)	2062A	0.5			
R&I (INCLUDES SEAL)	2062B	0.5			
REMOVE, SEAL, REINSTALL	2062D	0.5			
CAP SEAL	2062S	0.2			
R&R (COVER)	2064A	0.2			
R&R (CRANK HANDLE)	2065A	0.1			
R&R CRANK MECHANISM)	2066A	0.2			
R&R (FAN BLADE)	2067A	0.2			
R&R (FAN MOTOR)	2068A	0.3			
R&R (GARNISH)	2069A	0.1			
R&R (SCREEN)	2070A	0.1			
R&R (SWITCH)	2291A	0.2			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>ATTACHMENT-ROOF (CONT.)</u>					
ROOF VENT- POWERED (3 SPEED)					
R&R	2440A	0.5	X		
R&R (GARNISH)	2441A	0.1			
R&R (MOTOR)	2442A	0.3			
R&R (LIFT ARM ASSEMBLY)	2443A	0.2			
R&R (DOME)	2444A	0.2			
R&R (CIRCUIT BOARD)	2445A	0.5	X		
R&R (SCREEN)	2446A	0.1			
R&R (CRANK KNOB) 2447A		0.1			
R&R (FAN BLADE)	2448A	0.1			
R&R (LIFT MOTOR)	2449A	0.2			
R&R (REMOTE)	2450A	0.1			
SKY LIGHT					
R&R	2071A	0.5			
R&I	2071B	0.5			
CAP SEAL	2071S	0.2			
R&R (GARNISH)	2149A	0.2			
<u>ATTACHMENTS-EXTERIOR SIDEWALL</u>					
BATTERY BEZEL (FRONT WALL)					
R&R	2413A	0.2			
R&I	2413B	0.2			
REMOVE, SEAL, REINSTALL	2413D	0.2			
BEZEL-FRAME EXTENSION					
R&R	2152A	0.2			
R&I	2152B	0.2			
BEZEL-ENTRY STEP CUT OUT					
R&R	2320A	0.2			
HATCH (RADIO, WATER PANEL, CRANK)					
R&R	2321A	0.1			
R&I	2321B	0.1			
CABLE HATCH					
R&R	2030A	0.2			
R&I	2030B	0.2			
REMOVE, SEAL, REINSTALL	2030D	0.2			
CABLE/PHONE JACK					
R&R	7315A	0.2		X	
DOOR HOLDER – WALL MOUNT					
R&R (1-2 pcs.)	2048A	0.1			
DOOR STOP- ENTRY					
R&R	2126A	0.1			
R&I	2126B	0.1			
DRIP CAP					
R&R	2031A	0.3			
R&I	2031B	0.3			
DRYER VENT					
R&R	8332A	0.2			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>ATTACHMENTS-EXTERIOR SIDEWALL (CONT.)</u>					
ENTERTAINMENT CENTER-OUTSIDE					
R&R	7145A	0.5		X	
R&I	7145B	0.5			
FENDER SKIRT					
R&R	2032A	0.4			
R&I	2032B	0.4			
REMOVE, SEAL, REINSTALL	2032D	0.4			
FUEL FILL BEZEL					
R&R	2033A	0.3			
R&I	2033B	0.3			
PAINT	2033P	0.2			
FUEL FILL HATCH					
R&R	2012A	0.1			
R&I	2012B	0.1			
GRAB HANDLE					
R&R	2035A	0.2			
R&I	2035B	0.2			
GUTTER SPOUT (1-2pcs.)					
R&R	2412A	0.1			
R&I	2412B	0.1			
CAP SEAL	2412S	0.1			
GRAB HANDLE-LIGHTED					
R&R	2034A	0.2			
R&I	2034B	0.2			
LABELS					
R&R (1-2 pcs.)	2729A	0.1			
LICENSE PLATE BRACKET					
R&R	2036A	0.1			
R&I	2036B	0.1			
MIRROR-SIDE VIEW-FOLDAWAY-CLASS "C"					
R&R	2332A	0.2		X	
R&I	2332B	0.2			
HEAD-R&R	2333A	0.1		X	
ADJUST	2333J	0.2			
ARM-R&R	2334A	0.2			
MIRROR-SIDEVIEW-CLASS "A"					
R&R	2042A	0.2		X	
R&I	2042B	0.2			
HEAD-R&R	2325A	0.1		X	
MIRROR-SIDEVIEW-ELECTRIC W/REMOTE- CLASS "A"					
R&R	2043A	0.4		X	
R&I	2043B	0.4			
DIRECTIONAL SWITCH-R&R	2046A	0.3		X	
HEAD-R&R	2049A	0.3		X	
HEATER SWITCH	7097A	0.2			
PLAQUE/INSIGNIA					
R&R	2037A	0.1			
R&I	2037B	0.1			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>ATTACHMENTS-EXTERIOR SIDEWALL (CONT.)</u>					
RANGE VENT					
R&R	8146A	0.2			
R&I	8146B	0.2			
RECEPTACLE (120V EXTERIOR)					
R&R	2038A	0.2			
R&I	2038B	0.2			
RECEPTACLE (50 AMP. SHORE LINE)					
R&R	7318A	0.4			
R&I	7318B	0.2			
REMOVE, SEAL, REINSTALL	7318D	0.2			
REFLECTOR					
R&R	2275A	0.1			
R&I	2275B	0.1			
SEWER HOSE HOLDER					
R&R	2041A	0.2			
CAP SEAL	2041S	0.1			
<u>COMPARTMENT (EXTERIOR)</u>					
COMPARTMENT (LINER)-GALVANIZED					
REPAIR	2133C	ST			
SEAL	2133S	0.2			
COMPARTMENT (LINER) – FELT					
R&R	2342A	0.3			
REPAIR	2342C	0.2			
RESECURE	2342R	0.2			
REFRIGERATOR COMPARTMENT					
SEAL	2414S	0.2			
STAORAGE COMPARTMENT TRAY W/REINFORCEMENT					
R&R	2367A	0.1			
<u>DECAL</u>					
DECAL – R&R	2176A	0.5			
<u>DÉCOR PANEL</u>					
DÉCOR PANEL					
R&R	2177A	ST			
INSTALL					
(COMPLETE GRAPHICS PER SIDEWALL)	2177I	4.0			
<u>ENTRANCE DOOR & FRAME ASSEMBLY</u>					
ENTRANCE DOOR & FRAME ASSEMBLY					
R&R	2120A	1.0			
R&I	2120B	1.0			
REMOVE, SEAL, REINSTALL	2120D	1.0			
PAINT	2170P	ST	X		
STRIPE-INSTALL	2179I	0.2			
AWNING ROLLER					
R&R	2169A	0.1			
BULB SEAL (MAIN DOOR)					
R&R	2289A	0.3			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>ENTRANCE DOOR & FRAME ASSEMBLY (CONT.)</u>					
BUMPERS-DOOR					
R&R	2121A	0.1			
DOOR LOCK					
R&R	2123A	0.3			
SEAL IN PLACE	2123S	0.1			
DOOR STOP (GAS STRUT)					
R&R	2294A	0.1			
DOOR STOP BRACKET (GAS STRUT)					
R&R	2295A	0.2			
RELOCATE	2295F	0.2			
FOAM SEAL (SCREEN DOOR)					
R&R	2127A	0.2			
INSTALL	2127I	0.1			
SCREEN R&R	2129A	0.3			
SCREEN DOOR HANDLE					
R&R	2293A	0.1			
SCREEN DOOR					
R&R	2124A	0.3			
R&I	2124B	0.3			
SCREEN DOOR CATCH					
R&R	2133A	0.1			
SCREEN DOOR SLIDE COVER					
R&R	2125A	0.1			
STRIKER PLATE					
R&R	2148A	0.2			
WINDOW					
R&R	2128A	0.3			
SEAL IN PLACE	2128S	0.3			
TRIM RING					
R&R	2134A	0.3			
<u>BUS TYPE ENTRY DOOR</u>					
ENTRY DOOR					
R&R	2300A	2.0	X		X
R&I	2300B	1.5			
REMOVE, SEAL, REINSTALL	2300D	1.5			
PAINT	2170P	ST	X		
LOCK ASSEMBLY					
R&R	2301A	0.7			X
KEYLESS ENTRY LOCK					
R&R	2307A	0.7			X
INTERIOR PANEL					
R&R	2302A	0.3			
SCREEN DOOR					
R&R	2304A	0.3			X
SCREEN DOOR LATCH					
REPLACE	2305A	0.1			X
BULB SEAL R&R	2306A	0.5			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>FIBERGLASS/ABS ATTACHMENTS</u>					
BUMPER -FIBERGLASS					
R&R	2326A	1.0	X		
REPAIR	2326C	ST			
CAPS					
CORNER CAPS-ABS PLASTIC					
RADIUS CORNER-CAB AROUND					
R&R	2161A	1.5			
R&I	2161B	1.5			
REMOVE, SEAL, REINSTALL	2161D	1.5			
RADIUS CORNER-VERTICAL					
R&R	2159A	0.9			
R&I	2159B	0.9			
REMOVE, SEAL, REINSTALL	2159D	0.9			
ROOF EDGE-RADIUS-EACH SIDE					
R&R	2158A	1.2			
R&I	2158B	1.2			
REMOVE, SEAL, REINSTALL	2158D	1.2			
FRONT CAP 1-PIECE- CLASS "A"					
R&R	2082A	ST	X		
REPAIR	2082C	ST	X		
FRONT CAP 2-PIECE CLASS "A"					
R&R-UPPER	2116A	ST	X		
REPAIR	2116C	ST	X		
R&R-LOWER	2117A	ST	X		
REPAIR	2117C	ST	X		
REAR CAP -CLASS "C"					
R&R	2083A	ST	X		
REPAIR	2083C	ST	X		
ROOF- FIBERGLASS					
R&R	2399A	ST	X		
REPAIR	2399C	ST	X		
HEADLIGHT BEZEL					
HEADLIGHT BEZEL					
R&R	2327A	0.1			
UP & ANGLES					
ABS PLASTIC					
R&R	2099A	4.5	X		
REPAIR	2099A	ST			
FIBERGLASS					
R&R	2329A	3.5	X		
REPAIR	2329C	ST			
<u>GRILL</u>					
GRILL					
R&R (LOUVERED TYPE)	2088A	0.8	X		X
R&R (BAR TYPE)	2089A	0.2			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>GRILL CONT.</u>					
GRILL SCREEN					
R&R	2090A	0.3			
RESECURE	2090R	0.2			
<u>HOOD</u>					
HOOD					
R&R					
(INCLUDES ATTCH. & STRIPING)	2093A	2.0	X		
R&I	2093B	0.7			
ADJUST	2093J	0.2			
REPAIR FIBERGLASS	2093C	ST	X		
HOOD HINGE, DUAL					
R&R	2339A	1.5		X	
HOOD HINGE, SINGLE					
R&R	2094A	0.3		X	
HOOD LOCK					
R&R	2095A	0.1			
HOOD RELEASE CABLE					
R&R	2178A	0.5		X	
HOOD SUPPORT ROD					
R&R	2096A	0.1			
<u>MOLDINGS</u>					
AWNING RAIL					
R&R	2150A	1.0			
R&I	2150B	1.0			
REMOVE, SEAL, REINSTALL	2150D	1.0			
CAP SEAL	2150S	0.2			
CORNER MOLDINGS					
FRONT-DS					
R&R	2400	0.8			
R&I	2400B	0.8			
REMOVE, SEAL, REINSTALL	2400D	0.8			
CAP SEAL	2400S	0.2			
FRONT-ODS					
R&R	2401A	0.8			
R&I	2401B	0.8			
REMOVE, SEAL, REINSTALL	2401D	0.8			
CAP SEAL	2401S	0.2			
REAR-DS					
R&R	2402A	0.8			
R&I	2402B	0.8			
REMOVE, SEAL, REINSTALL	2402D	0.8			
CAP SEAL	2402S	0.2			
REAR-ODS					
R&R	2403A	0.8			
R&I	2403B	0.8			
REMOVE, SEAL, REINSTALL	2403D	0.8			
CAP SEAL	2403S	0.2			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>MOLDING (CONT.)</u>					
FLOOR LINE MOLDING					
DS WALL					
R&R (Includes aluminum retainer)	2165A	0.5			
CAP SEAL	2165S	0.2			
ODS WALL					
R&R (Includes aluminum retainer)	2166A	0.5			
CAP SEAL	2166S	0.2			
REAR WALL					
R&R (Includes aluminum retainer)	2167A	0.3			
CAP SEAL	2167S	0.2			
LOWER WALL MOLDINGS					
DS LOWER WALL					
R&R	2404A	0.5			
R&I	2404B	0.5			
CAP SEAL	2404S	0.2			
ODS LOWER WALL					
R&R	2405A	0.5			
R&I	2405B	0.5			
CAP SEAL	2405S	0.2			
MISC. MOLDINGS					
GASKET(RUBBER)-CAB TO BUMK FLOOR-MINI					
R&R	2154A	1.3			
ROOF MOLDINGS					
ROOF EDGE-DS					
R&R	2406A	1.2			
R&I	2406B	1.2			
REMOVE, SEAL, REINSTALL	2406D	1.2			
CAP SEAL	2406S	0.3			
ROOF EDGE-ODS					
R&R	2407A	1.2			
R&I	2407B	1.2			
REMOVE, SEAL, REINSTALL	2407D	1.2			
CAP SEAL	2407S	0.3			
ROOF FRONT					
R&R	2408A	0.5			
R&I	2408B	0.5			
REMOVE, SEAL, REINSTALL	2408D	0.5			
CAP SEAL	2408S	0.2			
ROOF REAR					
R&R	2409A	0.5			
R&I	2409B	0.5			
REMOVE, SEAL, REINSTALL	2409D	0.5			
CAP SEAL	2409S	0.2			
SCREW COVERS					
INSERT-R&R (EACH 10')	2162A	0.1			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>MOLDINGS (CONT.)</u>					
SCREW COVERS (CONT.)					
SELF STICK SCREW COVER (EACH SIDEWALL)					
R&R	2341A	0.5			
RESECURE	2341R	0.2			
CAP SEAL	2341S	0.1			
SNAP COVER					
R&R (EACH 7')	2340A	0.1			
R&I (EACH 7')	2340B	0.1			
<u>PAINT STRIPE</u>					
PAINT OVERSPRAY-CLEAN	2176E	0.2			
EXTERIOR PAINT REPAIR	2170P	ST	X		
<u>STEP-ENTRYDOOR</u>					
STEP-ENTRY DOOR-ELECTRIC					
R&R	2210A	0.5	X		X
R&I	2210B	0.5			
PAINT	2210P	0.2			
STEP SWITCH (DOOR MOUNT)					
R&R	2211A	0.5			
FRAME					
R&R	2219A	1.0			
GEAR KIT					
R&R	2274A	0.8			
MOTOR					
R&R	2213A	0.6			
REGULATOR/CONTROL MODULE					
R&R	2214A	0.6			X
STEP DOWN SWITCH (STEP MOUNT)					
REPLACE	2209A	0.4			
RESECURE	2209R	0.2			
STRIKER PLATE					
R&R	2216A	0.1			
NO SKID TAPE (BUMPER OR STEP)					
R&R	2201A	0.2			
<u>STRUCTURE</u>					
CABOVER					
BUNK FLOOR					
R&R	2345A	ST	X		
REPAIR	2345C	ST	X		
FRONT WALL-MINI					
ASSEMBLY-R&R	2346A	10.0	X		
ASSEMBLY-REPAIR	2346C	ST			
SKIN ONLY-R&R	2352A	8.0	X		
SKIN ONLY- REPAIR	2352C	ST	X		



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>STRUCTURE (CONT.)</u>					
REAR WALL					
COMPLETE ASSEMBLY-R&R	2185A	ST	X		
SKIN (MOTORIZED)					
R&R	2383A	ST	X		
REPAIR	2383C	ST	X		
RESECURE	2383R	ST	X		
ROOF					
LAMINATED COMPLETE ASSEMBLY					
R&R	2180A	ST	X		
UNDERLAYMENT-PERSHEET					
R&R	2181A	1.0	X		
FOAM-PER SHEET					
R&R	2182A	1.5	X		
SIDEWALLS					
COMPLETE ASSEMBLY					
R&R	2184A	ST	X		
REATTACH TO FLOOR	2184R	ST			
SKIN (MOTORIZED)					
REPAIR	2193C	ST	X		
SLIDE-OUT END WALL (FRONT OR REAR)					
REPLACE	2384A	ST	X		
REPAIR	2384C	ST	X		
SLIDE-OUT REAR WALL					
REPLACE	2385A	ST	X		
REPAIR	2385C	ST	X		
<u>UNDERBELLY MATERIAL</u>					
ACCESS PANEL					
R&I	2292B	0.3			
RESECURE	2292R	0.3			
UNDERBELLY MATERIAL (DARCO/TYPAR)					
REPAIR	2146C	ST			
RESECURE	2146R	0.3			
SEAL	2146S	0.3			
<u>WHEEL WELL</u>					
WHEEL WELL					
R&R-COMPLETE	2215A	1.5			
SEAL (W/O REMOVAL)	2215S	0.2			
<u>WINDOWS</u>					
NOTE: R&I IS TYPICALLY USED FOR REPAIRS INVOLVING ACCESS. REMOVE, SEAL AND REINSTALL IS PROVIDED FOR REPAIR INVOLVING A SEAL FAILURE. ** CAP SEALING OF WINDOWS NOT WARRANTABLE**					
BATH					
R&R	2700A	0.8	X		
R&I	2700B	0.8			
REMOVE, SEAL, REINSTALL	2700D	0.8			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>WINDOWS (CONT.)</u>					
BEDROOM					
DOOR SIDE-FRONT					
R&R	2701A	1.0	X		
R&I	2701B	1.0			
REMOVE, SEAL, REINSTALL	2701D	1.0			
OFF-DOOR SIDE-FRONT					
R&R	2702A	1.0	X		
R&I	2702B	1.0			
REMOVE, SEAL, REINSTALL	2702D	1.0			
DOOR SIDE-REAR					
R&R	2703A	1.0	X		
R&I	2703B	1.0			
REMOVE, SEAL, REINSTALL	2703D	1.0			
OFF-DOOR SIDE-REAR					
R&R	2704A	1.0	X		
R&I	2704B	1.0			
REMOVE, SEAL, REINSTALL	2704D	1.0			
CABOVER					
FRONT					
R&R	2705A	1.0	X		
R&I	2705B	1.0			
REMOVE, SEAL, REINSTALL	2705D	1.0			
DOOR SIDE					
R&R	2706A	0.8	X		
R&I	2706B	0.8			
REMOVE, SEAL, REINSTALL	2706D	0.8			
OFF-DOOR SIDE					
R&R	2707A	0.8	X		
R&I	2707B	0.8			
REMOVE, SEAL, REINSTALL	2707D	0.8			
COCKPIT					
DRIVERS					
R&R	2708A	1.0	X		
R&I	2708B	1.0			
REMOVE, SEAL, REINSTALL	2708D	1.0			
PASSENGER					
R&R	2709A	1.0	X		
R&I	2709B	1.0			
REMOVE, SEAL, REINSTALL	2709D	1.0			
DINETTE					
DOOR SIDE					
R&R	2710A	1.0	X		
R&I	2710B	1.0			
REMOVE, SEAL, REINSTALL	2710D	1.0			

NOTE: R&I IS TYPICALLY USED FOR REPAIRS INVOLVING ACCESS. REMOVE, SEAL, AND REINSTALL IS PROVIDED FOR REPAIRS INVOLVING A SEAL FAILURE. ** CAP SEALING OF WINDOWS NOT WARRANTABLE**



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>WINDOWS (CONT.)</u>					
DINETTE (CONT.)					
OFF-DOOR SIDE					
R&R	2711A	1.0	X		
R&I	2711B	1.0			
REMOVE, SEAL, REINSTALL	2711D	1.0			
FRONT WALL					
R&R	2719A	1.0	X		
R&I	2719B	1.0			
REMOVE, SEAL, REINSTALL	2719D	1.0			
HALL					
R&R	2720A	0.8	X		
R&I	2720B	0.8			
REMOVE, SEAL, REINSTALL	2720D	0.8			
KITCHEN					
R&R	2712A	0.8	X		
R&I	2712B	0.8			
REMOVE, SEAL, REINSTALL	2712D	0.8			
LOUNGE					
R&R	2713A	1.0	X		
R&I	2713B	1.0			
REMOVE, SEAL, REINSTALL	2713D	1.0			
NOTE: R&I IS TYPICALLY USED FOR REPAIRS INVOLVING ACCESS. REMOVE, SEAL AND REINSTALL IS PROVIDED FOR REPAIRS INVOLVING A SEAL FAILURE. ** CAP SEALING OR WINDOWS NOT WARRANTABLE**					
REAR WALL					
R&R	2721A	1.0	X		
R&I	2721B	1.0			
REMOVE, SEAL, REINSTALL	2721D	1.0			
SLIDE-OUT ROOM					
DINETTE					
R&R	2716A	1.0	X		
R&I	2716B	1.0			
REMOVE, SEAL, REINSTALL	2716D	1.0			
END-WALL-FRONT					
R&R	2714A	0.8	X		
R&I	2714B	0.8			
REMOVE, SEAL, REINSTALL	2714D	0.8			
END-WALL-REAR					
R&R	2715A	0.8	X		
R&I	2715B	0.8			
REMOVE, SEAL, REINSTALL	2715D	0.8			
SOFA					
R&R	2717A	1.0	X		
R&I	2717B	1.0			
REMOVE, SEAL, REINSTALL	2717D	1.0			



EXTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>WINDOW COMPONENTS</u>					
CLAMP RING					
R&R	2256A	0.2			
R&I	2256B	0.2			
TOUCH UP (1-2 RINGS)	2256X	0.1			
ESCAPE WINDOW					
GLASS					
R&R	2235A	0.5			
GLASS TO FRAME-SEAL	2233S	0.5			
LATCH					
R&R (PAIR)	2236A	0.3			
ADJUST (PAIR)	2236J	0.2			
GASKET					
R&R	2237A	0.5			
HINGE					
R&R	2234A	0.4			
SCREEN					
R&R	2249A	0.1			
R&I	2249B	0.1			
REPAIR (REPLACE MATERIAL)	2249C	0.3			
SCREEN CLIPS					
R&R (EACH WINDOW)	2250A	0.1			
INSTALL (EACH WINDOW)	2250I	0.1			
SLIDER WINDOW					
FELT- R&R	2243A	0.2			
GLASS- R&R	2244A	0.5			
GLASS TO FRAME- R&R	2244S	0.5			
LATCH- R&R	2245A	0.1			
GASKET -R&R	2246A	0.5			
TRACK – R&R	2247A	0.2			
<u>WINDSHIELDS</u>					
DRIVERS SEAT					
R&R	2263A	2.2	X		
REPAIR	2263C	ST	X		
SEAL	2263S	0.3	X		
PASSENGER SIDE					
R&R	2264A	2.2	X		
REPAIR	2264C	ST	X		
SEAL	2264S	0.3			
ONE PIECE					
R&R	2265A	5.0	X		
REPAIR	2265C	ST	X		
SEAL	2265S	0.3			
RUBBER TRIM					
R&R	2261A	1.0			
RESECURE	2261R	0.2			



INTERIOR

ABOUT THIS SECTION:

ALL LABOR ALLOWANCES INCLUDE ACCESS, DIAGNOSIS, REMOVE AND REINSTALL OF COMPONENTS, SET-UP, AND TESTING UNLESS OTHERWISE NOTED.

COMPONENT

- BEDS
- CABINetry
- CEILING
- CLOCK
- COUNTERTOPS
- DASH
- DOORS
- DRAWERS
- ENGINE COVER
- ENTRY DOOR HAND RAIL
- FLOOR
- FLOOR COVERINGS
- HARDWARE
- MAGAZINE RACK
- MIRROR-WALL MOUNT
- SEAT BELTS
- SHELF LAMINATED
- SLIDE OUT ROOM
- SLIDE OUT SYSTEMS
- SPICE RACK
- SPINDLE ASSEMBLY
- STEP WELL
- TABLES
- TRIM-INTERIOR
- TV SHELF
- WALLS
- WOOD PLUGS



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
BEDS					
CABOVER-MINI					
BUNK CUSHION SLIDE					
R&R	3088A	0.2			
ADJUST	3088J	0.2			
BUNK CUSHION STRAP					
R&R	3162A	0.2			
FLIP DOWN SOFA/ J-LOUNGE					
FACER BOARD					
R&R	3017A	0.2			
R&I	3017B	0.2			
REPAIR	3017C	0.2			
FIXED SECTION					
R&R	3018A	0.3			
R&I	3018B	0.3			
REPAIR	3018C	0.2			
SLIDER SECTION					
R&R	3019A	0.3			
R&I	3019B	0.3			
REPAIR	3019C	0.2			
HIDE-A-BED					
ASSEMBLY					
R&R	3060A	1.0			
R&I	3060B	0.5			
REPAIR	3060C	0.3			
BRASS BOLT LATCH					
R&R	3290A	0.1			
FRONT					
R&R	3061A	0.5			
R&I	3061B	0.4			
REPAIR	3061C	0.3			
RAILS					
R&R	3062A	0.1			
R&I	3062B	0.1			
NOTE: SEE SOFT GOODS FOR MATTRESS.					
QUEEN/KING					
BASE					
R&I	3050B	1.0			
PLATFORM					
R&R	3052A	0.3			
R&I	3052B	0.1			
REPAIR	3052C	0.2			
SIDE/END PANEL					
R&R	3053A	0.5			
REPAIR	3053C	0.2			
STUD (CLEAT)					
R&R	3054A	0.2			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>BEDS (CONT.)</u>					
<u>QUEEN/KING (CONT.)</u>					
HINGE					
R&R	3307A	0.3			
ENGINE COMPARTMENT SEAL-REAR DIESEL					
R&R	3051A	0.5			
ENGINE COMPARTMENT RETAINING HARDWARE -REAR DIESEL					
R&R	3263A	0.2			
R&I	3263B	0.2			
<u>TWIN</u>					
BASE					
R&I	3070B	0.8			
PLATFORM					
R&R	3072A	0.3			
R&I	3072B	0.1			
REPAIR	3072C	0.2			
SIDE/END PANEL					
R&R	3073A	0.5			
REPAIR	3073C	0.2			
STUD (CLEAT)					
R&R	3074A	0.2			
<u>CABINETRY</u>					
CABINET COPONENTS					
NOTE: CABINET DOORS LOCATE UNDER DOOR SECTION.					
<u>BATH LAVATORY</u>					
ASSEMBLY					
R&I	3037B	1.2			
TOUCH-UP	3037X	0.2			
ACCESS PANEL					
R&R	3142A	0.2			
R&I	3142B	0.1			
INSTALL	3142I	0.2			
BACKER					
R&R	3144A	0.5			
R&I	3144B	0.5			
INSTALL	3144I	0.3			
RELOCATE	3144F	0.5			
BOTTOM PANEL					
R&R	3480A	0.5			
REPAIR	3480C	0.2			
DIVIDER PANEL					
R&R	3612A	0.2			
R&I	3612B	0.1			
INSTALL	3612I	0.3			
RESECURE	3612R	0.1			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>CABINETRY (CONT.)</u>					
BATH LAVATORY (CONT.)					
END PANEL					
R&R	3120A	0.5			
REPAIR	3120C	0.2			
FALSE BOTTOM					
R&R	3100A	0.2			
REPAIR	3100C	0.1			
FALSE PANEL					
R&R	3482A	0.2			
REPAIR	3482C	0.1			
FRONT PANEL					
R&R	3130A	0.5			
REPAIR	3130C	0.2			
PRE-FINISHED END					
R&R	3481A	0.5			
REPAIR	3481C	0.2			
SHELF					
R&R	3140A	0.2			
REPAIR	3140C	0.1			
STUD (CLEAT)					
R&R	3110A	0.2			
REPAIR	3110C	0.1			
STYLE					
R&R	3141A	0.3			
REPAIR	3141C	0.2			
WIRING/PLUMBING COVER					
R&R	3143A	0.2			
R&I	3143B	0.1			
INSTALL	3143I	0.2			
BASE CABINET					
ASSEMBLY					
R&I	3030B	0.5			
TOUCH-UP (PER CABINET)	3030X	0.2			
CLOSET-LINEN/SHIRT					
ASSEMBLY					
R&I	3034B	0.5			
TOUCH-UP (PER CABINET)	3034X	0.2			
DINETTE					
BASE ASSEMBLY					
R&I	3013B	0.4			
TOUCH-UP (PER CABINET)	3013X	0.2			
STORAGE LID					
R&R	3063A	0.2			
REPAIR	3063C	0.2			
ENTERTAINMENT CENTER CABINET					
ASSEMBLY					
R&I	3022B	ST			
TOUCH-UP (PER CABINET)	3022X	0.2			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>CABINETRY (CONT.)</u>					
KITCHEN BASE					
ASSEMBLY					
R&I	3021B	ST	X		
TOUCH-UP (PER CABINET)	3021X	0.2			
MEDICINE CABINET					
ASSEMBLY					
R&I	3024B	0.3			
TOUCH-UP (PER CABINET)	3024X	0.2			
MICROWAVE OVERHEAD					
ASSEMBLY					
R&I	3038B	0.5			
TOUCH-UP (PER CABINET)	3038X	0.2			
NIGHT STAND					
ASSEMBLY					
R&I	3026B	0.2			
TOUCH-UP	3026X	0.2			
OVERHEAD CABINET					
ASSEMBLY					
R&I	3028B	0.5			
TOUCH-UP (PER CABINET)	3028X	0.2			
PANTRY					
ASSEMBLY					
R&I	3029B	0.5			
TOUCH-UP (PER CABINET)	3029X	0.2			
REFRIGERATOR CABINET					
ASSEMBLY					
R&I	3031B	2.2			
TOUCH-UP (PER CABINET)	3031X	0.2			
STEP BASE					
REINSTALL	3039B	0.3			
REPAIR	3039C	0.3			
TV CABINET					
ASSEMBLY					
R&I	3015B	0.8			
TOUCH-UP (PER CABINET)	3015X	0.2			
TRIM RING					
R&R	8245A	0.2			
R&I	8245B	0.2			
TOUCH-UP	8245X	0.1			
<u>CEILING</u>					
BATTEN					
REPLACE	3153A	0.1			
RESECURE	3153R	0.1			
FABRIC					
R&R	3157A	ST	X		
RESECURE	3157R	ST			
REPAIR	3157C	0.3			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>CEILING (CONT.)</u>					
PANEL-LAMINATED					
R&R	3151A	2.5			
PAINTED-COMPLETE	3151P	1.0			
RESECURE	3151R	0.3			
TOUCH-UP	3151X	0.1			
PANEL-NON-LAMINATED					
R&R	3152A	2.5			
R&I	3152B	1.9			
RESECURE	3152R	0.2			
PAINT-COMPLETE	3152P	1.0			
TOUCH-UP	3152X	0.1			
SELF-STICK BATTEN					
R&R	3158A	0.3			
RESECURE	3158R	0.1			
STUD/BACKER					
R&R	3150A	ST	X		
RESECURE	3150R	ST	X		
INSTALL	3150I	ST	X		
<u>CLOCK</u>					
CLOCK (WALL)-R&R	3160A	0.1		X	
<u>COUNTERTOPS</u>					
NOTE: LABOR ALLOWANCES INCLUDE NEW GIMP AND CLEATS.					
NOTE: TIMES DO NOT INCLUDE REMOVE AND REINSTALL OF ATTACHMENTS. THESE TIMES MAY BE ADDED AS SEPARATE LINE ITEMS.					
BASE CABINET					
R&R	3190A	0.5			
R&I	3190B	0.5			
SEAL TO WALL	3190S	0.1			
BATH VANITY					
R&R	3170A	0.3			
R&I	3170B	0.3			
SEAL TO WALL	3170S	0.1			
BEDROOM DRESSER					
R&R	3171A	0.5			
SEAL TO WALL	3171S	0.1			
KITCHEN					
R&R	3174A	0.7			
R&I	3174B	0.7			
SEAL TO WALL	3174S	0.1			
NIGHTSTAND-QB/DOUBLE					
R&R	3178A	0.3			
R&I	3178B	0.3			
SEAL	3178S	0.1			
NIGHTSTAND-TWIN					
R&R	3179A	0.3			
R&I	3179B	0.3			
SEAL	3179S	0.1			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>COUNTERTOPS (CONT.)</u>					
NOTE: LABOR ALLOWANCES INCLUDE NEW GIMP AND CLEATS.					
NOTE: TIMES DO NOT INCLUDE REMOVE AND REINSTALL OF ATTACHMENTS. THESE TIMES MAY BE ADDED AS SEPARATE LINE ITEMS.					
TV CABINET					
R&R	3177A	0.3			
SEAL	3177S	0.1			
COUNTERTOP ACCESSORIES					
CLEAT					
R&R	3189A	0.2			
R&I	3189B	0.2			
RESECURE	3189R	0.1			
INSTALL	3189I	0.2			
CORIAN TOP					
REPAIR	3483C	0.5			
R&R	3483A	ST	X		
CORIAN STOVE COVER					
R&R	3182A	0.1	X		
COUNTERTOP EDGING-"T"					
R&R	3180A	0.2			
RESECURE	3180R	0.1			
COUNTERTOP EDGING – WOOD					
R&R	3188A	0.3			
RESECURE	3188R	0.2			
COUNTERTOP EDGING (LAMINATED)					
R&R	3613A	0.4			
RESECURE	3613R	0.2			
COUNTERTOP EXTENSION					
R&R	3181A	0.2			
REPAIR	3181C	0.1			
TOUCH-UP	3181X	0.1			
COUNTERTOP EXTENSION BRACKET					
R&R	3383A	0.2			
ADJUST	3383J	0.1			
COUNTERTOP LAMINATION					
RESECURE	3181R	0.2			
TOUCH-UP	3181X	0.2			
CUTTING BOARD					
R&R	3185A	0.1			
GIMP					
R&R	3422A	0.1			
R&I	3422B	0.1			
RESECURE	3422R	0.1			
INSTALL	3422I	0.1			
SINK COVER					
R&R	3183A	0.1			
SPLASH GUARD					
R&R	3175A	0.2			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>DASH (CLASS A)</u>					
COWEL BOARD- FRONT					
R&R	3207A	0.5			
R&I	3207B	0.4			
RESECURE	3207R	0.2			
COWEL BOARD-UPPER (HEADLINER) VINYL					
R&R	3199A	0.5			
RESECURE	3199R	0.2			
DASHBOARD – 1 PIECE					
R&R	3191A	3.0			
R&I	3191B	1.5			
RESECURE	3191R	0.3			
DASHBOARD- RIGHT HAND					
R&R	3205A	1.0			
R&I	3205B	1.0			
RESECURE	3205R	0.3			
DASHBOARD- LEFT HAND (POD)					
R&R	3206A	1.0			
R&I	3206B	1.0			
RESECURE	3206R	0.3			
DASH VINYL					
REPAIR	3202C	0.3			
PAD, A-PILLAR					
R&R	4151A	0.2			
R&I	4151B	0.2			
REPAIR	4151C	0.2			
POD – BACK-UP MONITOR					
R&R	3485A	0.2			
SCREW COVERS (1-10pcs.)	3209A	0.1			
SLIDING TRAY					
R&R	3208A	0.2			
R&I	3208B	0.2			
REPAIR	3208C	0.2			
SUN VISOR					
R&R	3201A	0.2			
RESECURE	3201R	0.1			
SUN VISOR (ELECTRIC)					
R&R	3604A	0.4	X		X
WOOD GRAIN INLAY- DRIVERS SIDE COCKPIT					
CENTER- R&R	3193A	1.0			
CENTER- R&I	3193B	0.3			
LEFT- R&R	3196A	1.0			
LEFT- R&I	3196B	0.2			
RIGHT- R&R	3194A	1.0			
RIGHT- R&I	3194B	0.2			
<u>DASH (CLASS C)</u>					
APPILQUE (DASH)					
R&R	3398A	0.7			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>DOORS</u>					
INTERIOR CABINET DOORS					
DOOR					
R&R	3210A	0.3			
R&I (PAIR)	3210B	0.1			
REPAIR	3210C	0.2			
TOUCH-UP (FILL OR STAIN)	3210X	0.1			
CATCH					
R&R (1-3 CATCHES)	3292A	0.1			
ETCHED GLASS					
REPLACE	3217A	0.3			
HANDLE					
R&R 1-3 HANDLES)	3302A	0.1			
HINGES					
R&R (PAIR)	3293A	0.1			
MESH					
R&R	3215A	0.2			
SPRING ROD					
R&R	3216A	0.1			
SLIDING GLASS CLOSET DOORS					
GLASS ONLY					
R&R	3245A	0.6			
CATCH					
R&R	3247A	0.1			
FRAME					
R&R	3246A	0.6			
TRACK					
R&R	3248A	0.3			
HOLLOW CORE DOOR-HINGED					
DOOR					
R&R	3220A	0.5			
R&I	3220B	0.2			
REPAIR	3220V	0.1			
LOCK					
R&R	3221A	0.2			
ADJUST	3221J	0.1			
HOLLOW CORE DOOR-SLIDING/POCKET					
DOOR					
R&R	3230A	0.5			
BOLT LATCH					
R&R	3231A	0.1			
LOCK					
R&R	3232A	0.2			
TRACK AND ROLLERS					
R&R	3301A	0.5			
GUIDE					
R&R	3233A	0.1			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>DOORS (CONT.)</u>					
ACCORDIAN/BI-FOLD DOOR					
DOOR R&R	3240A	0.4			
LATCH R&R	3241A	0.1			
STRAP R&R	3242A	0.1			
TRACK R&R	3300A	0.4			
TAMBOR DOOR					
R&R	3214A	0.1			
<u>DRAWERS</u>					
DRAWER					
R&R	3250A	0.2			
ADJUST (PER DRAWER)	3255J	0.1			
BREACKET-WALL MOUNT					
R&R	3257A	0.2			
FRONT					
R&R	3257A	0.2			
TOUCH-UP (PER DRAWER)	3251X	0.1			
DRAWER BOX					
R&R	3254A	0.3			
REPAIR	3254C	0.2			
GUIDE CABINET MOUNT					
R&R	3256A	0.1			
TRACK DRAWER MOUNT					
R&R	3304A	0.1			
BRACKET SUPPORT					
REPAIR	3258C	0.2			
<u>ENGINE COVER</u>					
ENGINE COVER (FIXED PORTION)					
R&R	3265A	1.5	X		
R&I	3265B	0.1			
ENGINE COVER (MOVABLE PORTION)					
R&R	3260A	1.0			
R&I	3260B	0.1			
ENGINE COVER- CLASS C – DRINK TRAY APPLIQUE					
R&R	3267A	0.7			
CARPET					
R&R	3266A	0.8			
RESECURE	3266R	0.2			
INSULATION					
REPLACE	3262A	0.4			
RESECURE	3262R	0.2			
RETAINING HARDWARE					
REPLACE	3263A	0.2			
REINSTALL	3363B	0.2			
WEATHER SEAL					
REPLACE	3264A	0.2			
RESECURE	3264R	0.1			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>DOORS (CONT.)</u>					
ENTRY DOOR HAND RAIL					
WOOD R&R	3380A	0.2			
BRASS R&R	3381A	0.3			
(OTHER) R&R	3382A	0.2			
<u>FLOOR</u>					
FLOOR-LAMINATED					
DECKING-SECTION					
R&R	3282A	ST	X		
REPAIR	3282C	0.5			
DECKING TO STEEL					
RESECURE	3282R	ST	X		
FLOOR TO CAB/SIDEWALL					
RESECURE	3285R	ST			
SEAL	3285S	0.4			
FLOOR TO TRUSS					
RESECURE	3288R	ST	X		
FLOOR – REINFORCE (ADD CROSSMEMBER)	1204I	0.5			
OPENING-SEAL	3451S	0.1			
FLOOR-NON-LAMINATED					
DECKING-SECTION					
R&R	3450A	1.5	X		
REPAIR	3450C	0.5			
RESECURE	3450R	0.5			
STUD (JOIST)					
R&R	3280A	1.5	X		
RESECURE	3280R	0.5			
INSTALL	3280I	1.0	X		
INSULATION					
R&R	3501A	ST	X		
R&I	3501B	ST			
OPENING-SEAL	3451S	0.1			
<u>FLOOR COVERINGS</u>					
NOTE: LABOR ALLOWANCE INCLUDE REMOVAL AND INSTALLATION OF PAD. A 24"X24" SECTION OF CARPET MUST BE RETURNED.					
<u>CARPET</u>					
BATH					
R&R	3270A	ST	X		X
R&I	3270B	0.5			
REPAIR	3270C	0.3			
BEDROOM					
R&R	3271A	ST	X		X
R&I	3271B	0.7			
REPAIR	3271C	0.3			
CAB AREA-MOTORIZED					
R&R	3275A	ST	X		X
R&I	3275B	0.5			
REPAIR	3275C	0.3			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>FLOOR COVERINGS (CONT.)</u>					
CARPET (CONT.)					
KITCHEN					
R&R	3272A	ST	X		X
R&I	3272B	0.5			
REPAIR	3272C	0.3			
LIVING AREA					
R&R	3277A	ST	X		X
R&I	3277B	0.8			
REPAIR	3277C	0.3			
SLIDE-OUT ROOM					
R&R	3446A	ST	X		X
R&I	3446B	0.8			
REPAIR	3446C	0.3			
STEP WELL					
R&R	3274A	1.0	X		X
R&I	3274B	0.5			
REPAIR	3274C	0.3			
VINYL FLOORING					
ALL OTHER					
R&R	3284A	ST	X		X
R&I	3284B	ST			
REPAIR	3284C	0.5			
TRIM (BASE CABINETS)					
INSTALL	3421I	ST			
<u>HARDWARE</u>					
DOOR/DRAWER					
BRACKET-WALL MOUNT					
R&R	3257A	0.2			
CABINET DOOR CATCH					
R&R (1-3 CATCHES)	3292A	0.1			
CABINET DOOR HINGE					
R&R (PAIR)	3293A	0.1			
CABINET DOOR SPRING ROD					
R&R	3291A	0.1			
CURTAIN TRACK					
R&R	3298A				
R&I	3298B				
RELOCATE	3209F				
DOOR ROLLER					
R&R	3299A	0.3			
DOOR TRACK-ACCORDION					
R&R	3300A	0.4			
DOOR TRACK & ROLLER – SLIDING					
R&R	3301A	1.3			
DRAWER/DOOR HANDLE					
R&R (1-3pcs.)	3302A	0.1			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>HARDWARE (CONT.)</u>					
DOOR/DRAWER CONT.					
DRAWER GUIDE CABINET MOUNT R&R	3256A	0.1			
DRAWER TRACK-DRAWER MOUNT R&R	3304A	0.1			
MISCELLANEOUS					
ADJUSTABLE SHELF SUPPORT R&R (1-2 PCS.)	3442A	0.2			
BED SHOCK R&R	3341A	0.1			
RELOCATE	3341F	0.2			
BRASS BOLT LATCH R&R	3290A	0.1			
BRASS RAIL W/ STANCHIONS R&R	3291A	0.2			
CARPET BAR R&R	3295A	0.3			
R&I	3295B	0.3			
INSTALL	3295I	0.3			
CLOSET ROD R&R	3296A	0.3			
CURTAIN ROD R&R	3317A	0.1			
CURTAIN ROD BRACKET R&R(PAIR)	3318A	0.1			
CURTAIN ROLLER R&R	3297A	0.2			
CURTAIN TRACK R&R	3298A	0.2			
R&I	3298B	0.1			
RELOCATE	3298F	0.1			
PANTRY-SLIDE ASSEMBLY R&R	3441A	0.3			
R&I	3441B	0.3			
PIANO HINGE R&R	3307A	0.3			
SINK COVER GROMMET FINGER HOLE R&R	3305A	0.1			
SOAP DISH R&R	3308A	0.1			
PEDESTAL TABLE LEG R&R	3310A	0.1			
PEDESTAL LEG BASE FLOOR R&R	3311A	0.3			
PEDESTAL LEG BASE TABLE R&R	3312A	0.1			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>HARDWARE (CONT.)</u>					
<u>MISCELLANEOUS (CONT.)</u>					
TOILET TISSUE HOLDER					
R&R	3313A	0.1			
TOWEL BAR					
R&R	3314A	0.1			
TOWEL RING					
R&R	3315A	0.1			
<u>MAGAZINE RACK</u>					
R&R	3340A	0.1			
<u>MIRROR-WALL MOUNT</u>					
R&R	3360A	0.2			
RESECURE	3360R	0.2			
<u>SEAT BELTS</u>					
FLOOR MOUNT SEAT BELT					
R&R	3400A	0.1		X	
R&I	3400B	0.1			
INTEGRAL (PILOT SEAT)					
R&R	4335A	3.0	X	X	
REPAIR	4335C	0.3			
SIDE MOUNT SEAT BELTS					
R&R	3401A	0.1		X	
R&I	3401B	0.1			
<u>SELF-LAMINATED</u>					
SOFA- (INCLUDES INSTALLING NEW GIMP AND CLEATS)					
R&R	3036A	1.0			
<u>SLIDE OUT ROOM</u>					
<u>SLIDE-OUT ROOM</u>					
SMALL ROOM (LESS THAN 8')					
R&I	3354B	1.0	X		
LARGE ROOM (8' OR LARGER)					
R&I	3353B	2.5	X		
SLIDE OUT END WALL (FRONT OR REAR)					
R&R	2384A	ST	X		
REPAIR	2384C	ST	X		
SLIDE OUR REAR WALL					
R&R	2385A	ST	X		
REPAIR	2385C	ST	X		
<u>SLIDE-OUT FLOOR</u>					
FLOOR (COMPLETE)					
REPLACE	3535S	ST	X		
DECKING SECTION					
REPLACE	3536A	ST	X		
RESECURE	3536R	0.5			
UNDERBELLY MATERIAL (DARCO)					
REPLACE	3537A	ST	X		
REPAIR	3537C	0.3			
SEAL	3537S	0.3			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>SLIDE OUR ROOM (CONT.)</u>					
SLIDE-OUT FLOOR					
FLOOR BRACKET					
INSTALL	3538I	ST	X		
UNDERBELLY LUAN					
REPLACE	3539A	ST	X		
RESECURE	3539R	0.5			
NYLON RAMP					
REPLACE (ADD TIME FOR R&I)	3541A	0.1	X		
SET-UP					
NOTE: SET-UP CAN BE USED ONLY WHERE AN ASTERISK (*) IS INDICATED, AND CAN BE CLAIMED ONCE PER REPAIR ATTEMPT.					
NOTE: SET-UP INCLUDES; R&I INNER FLANGE AND MOVING ROOM TO ACCESS COMPONENTS FOR REPAIR.					
SMALL ROOM (LESS THAN 8')	3354T	0.5			
LARGE ROOM (8' OR LARGER)	3353T	0.8			
BREAK METAL					
RAIN GUTTER					
R&R	3524A	0.4			
SEAL	3524S	0.2			
REAR WALL					
R&R (LOWER)	3520A	ST			
SEAL (LOWER)	3520S	0.2			
R&R (SIDE)	3521A	ST			
SEAL (SIDE)		3521S	0.2		
R&R (UPPER)	3522A	ST			
SEAL (UPPER)	3522S	0.2			
WALL OPENING					
R&R (SPLASH PAN)	3523A	ST			
SEAL (SPLASH PAN)	3523S	0.2			
EXTRUSIONS					
ANGLE (END WALL TO REAR WALL)					
R&R	3518A	0.4			
R&I	3518B	0.4			
SEAL	3518S	0.2			
ANGLE (ROOF TO REAR WALL)					
R&R	3519A	0.6			
R&I	3519B	0.6			
SEAL	3519S	0.4			
T-RAIL (REAR WALL) BOTTOM (MOTORIZED ONLY)					
R&R	3512A	0.5			
R&I	3512B	0.4			
SEAL	3512S	0.2			
T-RAIL (SIDE)					
R&R	3513A	0.4			
R&I	3513B	0.3			
SEAL	3513S	0.2			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>SLIDE OUT ROOM (CONT.)</u>					
<u>EXTRUSIONS (CONT.)</u>					
T-RAIL (TOP)					
R&R	3514A	0.5			
R&I	3514B	0.4			
SEAL	3514S	0.2			
Z-RAIL (WALL OPENING) BOTTOM (MOTORIZED ONLY)					
*R&R	3515A	0.6			
*R&I	3515B	0.5			
*SEAL	3515S	0.2			
Z-RAIL (SIDE)					
*R&R	3516A	0.4			
*R&I	3516B	0.3			
*SEAL	3516S	0.2			
Z-RAIL (TOP)					
*R&R	3517A	0.6			
*R&I	3517B	0.5			
*SEAL	3517S	0.2			
INTERIOR					
NOTE: SET-UP CAN BE USED ONLY WHERE AN ASTERISK (*) IS INDICATED, AND CAN BE CLAIMED ONCE PER REPAIR ATTEMPT.					
FACERBOARD (WOOD)					
R&R (EACH pcs.)	3502A	0.3			
R&I (EACH pcs.)	3502B	0.1			
FABRIC TRIM					
R&R	3534A	0.1			
WOOD BLOCK					
R&R (1-3)	3503A	0.1			
FLOOR ROLLERS					
*R&R (1-5)	3505A	0.2			
*R&I	3505B	0.2			
INNER FLANGE					
R&I	3504B	0.6			
REPAIR	3504C	0.3			
SEAL	3504S	0.2			
MISCELLANEOUS					
BRACKET					
R&R	3506A	0.3			
R&I	3506B	0.3			
RESECURE	3506R	0.1			
BRACKET-RAM					
R&R	3507A	0.5			
R&I	3507B	0.5			
RESECURE	3507R	0.1			
RUBBER ROOF					
R&R	(PER LINEAR FOOT; INCLUDES SET-UP & R&I OF ATTACHMENTS)				
	3508A	0.4	X		
REPAIR	3508C	0.5			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>SLIDE OUT ROOM (CONT.)</u>					
MOLDING-EXTERIOR					
FLAT TRIM					
LOWER WALL					
R&R	3509A	0.2			
R&I	3509B	0.2			
REMOVE, SEAL, REINSTALL	3509D	0.2			
CAP SEAL	3509S	0.1			
LOWER REAR WALL					
R&R	3510A	0.3			
R&I	3510B	0.3			
REMOVE, SEAL & REINSTALL	3510D	0.3			
CAP SEAL	3510S	0.1			
UPPER END WALL					
R&R	3511A	0.2			
R&I	3511B	0.2			
REMOVE, SEAL, REINSTALL	3511D	0.2			
CAP SEAL	3511S	0.1			
CORNER CAP					
R&R	3540A	0.2			
R&I	3540B	0.2			
SEAL					
NOTE: SET-UP CAN BE USED ONLY WHERE AN ASTERISK (*) IS INDICATED, AND CAN BE CLAIMED ONCE PER REPAIR ATTEMPT.					
WIPER SEAL (OPENING) BOTTOM					
*R&R	3528A	0.6			
RESECURE	3528R	0.2			
WIPER SEAL SIDE					
*R&R	3529A	0.4			
RESECURE	3529R	0.2			
WIPER SEAL TOP					
*R&R	3530A	0.6			
RESECURE	3530R	0.2			
BULB SEAL (REAR WALL) BOTTOM (MOTORIZED ONLY)					
R&R	3527A	0.5			
RESECURE	3527R	0.2			
BULB SEAL SIDE					
R&R	3525A	0.3			
RESECURE	3525R	0.2			
BULB SEAL TOP					
R&R	3526A	0.5			
RESECURE	3526R	0.2			
<u>SLIDE OUT SYSTEMS</u>					
LIPPERT SLIDE-OUT SYSTEM					
CONTROL R&R	3596A	0.5			X
DRIVE CROSS SHAFT					
R&R	3550A	0.8			
GEAR R&R	3595A	0.8			
MOTOR R&R	3594A	1.0			X



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>SLIDE OUT SYSTEMS (CONT.)</u>					
LIPPERT SLIDE-OUT SYSTEM (CONT.)					
ROLLER R&R	3597A	0.8			
SHEAR PIN R&R	3598A	0.5			
SWITCH R&R	3599A	0.2		X	
NORCO CABLE SLIDE OUT					
CABLE					
R&R	3343A	0.8			
ADJUST	3343J	0.5			
CONTROL MODULE					
R&R	3344A	0.8		X	
EYE BOLT R&R	3346A	0.8			
GEAR R&R	3347A	1.0		X	
MOTOR R&R	3348A	0.5		X	
PULLEY R&R	3349A	1.2			
SWITCH R&R	3351A	0.2		X	
LIPPERT GEAR DRIVE SYSTEM					
MOTOR/GEAR BOX ASSEMBLY					
REPLACE	3600A	0.5		X	
GEAR REPLACE	3601A	0.5		X	
ACTUALOR REPLACE	3602A	0.5		X	
HEAD ASSEMBLY					
REPLACE	3603A	0.5		X	
GEAR RACK ASSEMBLY					
REPLACE	3604A	1.0		X	
CROSS SHAFT					
REPLACE	3605A	0.5		X	
SWITCH REPLACE	3606A	0.2		X	
<u>SPIGE RACK</u>					
SPIGE RACK					
R&R	3390A	0.1			
REPAIR	3390C	0.3			
SPINDLE ASSEMBLY					
R&R	3391A	0.5			
<u>STEP WELL</u>					
BATTERY COMPARTMENT LATCH					
REPLACE	3358A	0.2			
RUBBER TREAD					
R&R	2138A	0.5			
REPAIR	2138C	0.3			
STEP WELL COVER					
R&R	2139A	0.3			
STEP WELL					
REPAIR & REBUILD	2137C	2.0			
SEAL	2137S	0.3			
STEP WELL MOTOR					
R&R	2296A	0.5			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>TABLES</u>					
DINETTE SWINGDOWN					
R&R	3411A	0.2			
REPAIR	3411C	0.1			
RESECURE	3411R	0.3			
FREESTANDING TABLE					
R&R COMPLETE	3413A	0.2	X		
R&I	3413B	0.1			
FREESTANDING TABLE BASE					
R&R	3414A	0.2	X		
FREESTANDING TABLE TOP					
R7R	3415A	0.2	X		
PEDESTAL					
R&R	3410A	0.2			
REPAIR	3410C	0.1			
<u>TRIM-INTERIOR</u>					
CORNER TRIM					
R&R	3421A	0.1			
RESECURE	3421R	0.1			
CROWN MOLDING (EACH 8' pcs.)					
R&R	3429A	0.2			
R&I	3429B	0.2			
RESECURE	3429R	0.1			
DOOR CASING					
R&R	3425A	0.1			
RESECURE	3425R	0.1			
FLAT TRIM					
R&R	3420A	0.1			
RESECURE	3420R	0.1			
GALLEY RAIL					
R&R	3610A	0.2			
RESECURE	3610R	0.1			
GIMP					
R&R	3422A	0.1			
RESECURE	3422R	0.1			
SEAM TAPE					
REPLACE	3426A	0.2			
INSTALL	3426I	0.1			
U-CHANNEL					
R&R	3427A	0.1			
RESECURE	3427R	0.1			
WALL BORDER					
R&R	3611A	ST			
REPAIR	3611C	0.1			
RESECURE	3611R	0.1			



INTERIOR

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>TV SHELF</u>					
TV SHELF FOLDING					
R&R	3419A	0.3			
RESECURE	3419R	0.1			
<u>WALLS</u>					
NOTE: TIMES DO NOT INCLUDE REMOVE AND REINSTALL OF ATTACHMENTS. THESE TIMES MAY BE ADDED AS SEPARATE LINE ITEMS.					
<u>WALL-LAMINATED</u>					
EGS BACKER (GALVANIZED STEEL)					
R&R	3437A	ST	X		
INSTALL	3437I	ST			
FOAM R&R	3433A	1.5			
WALL PANEL					
R&R	3434A	2.5			
TOUCH-UP (FILL, STAIN, CLEAN)	3432X	0.1			
<u>WALL-NON- LAMINATED</u>					
INSULATION (FIBERGLASS BATT)					
R&R	3435A	0.2			
R&I	3435B	0.2			
PANEL DÉCOR					
R&R	3431A	1.0			
R&I	3431B	1.0			
RESECURE	3431R	0.1			
TOUCH-UP (FILL, STAIN, CLEAN)	3431X	0.1			
PANEL WOOD GRAIN					
R&R	3432A	1.0			
R&I	3432B	1.0			
RESECURE	3432R	0.1			
TOUCH-UP (FILL, STAIN, CLEAN)	3432X	0.1			
PANEL FABRIC					
R&R	3436A	ST			
RESECURE	3436R	0.3			
PEG BOARD					
R&R	3438A	0.5			
R&I	3438B	0.5			
RESECURE	3438R	0.1			
STUD/BACKER					
R&R	3430A	ST	X		
RESECURE	3430R	ST	X		
INSTALL	3430I	ST	X		
RELOCATE	3430F	ST	X		
<u>WOOD PLUGS</u>					
WOOD PLUGS (1-5)					
R&R	3440A	0.1			



SOFT GOODS

ABOUT THIS SECTION:

ALL LABOR ALLOWANCES INCLUDE ACCESS, DIAGNOSIS, REMOVE AND REINSTALL OF COMPONENTS SET-UP, AND TESTING UNLESS OTHER WISE NOTED.

WHERE AN ASTERISK (*) IS INDICATED, A LOCAL UPHOLSTERY SHOP CAN MAKE REPAIRS TO THE COMPONENT. SIMPLY CONTACT YOUR REGIONAL SERVICE MANAGER WITH AN ESTIMATE.

MARK DEFECTIVE AREAS OF RETURNED FABRIC.

COMPONENTS

- FURNITURE
- TREATMENTS



SOFT GOODS

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>FURNITURE</u>					
BUTTON					
BUTTON (CHAIR-CUSHION-PAD)					
R&R	4050A	0.1			
INSTALL	4050I	0.1			
*CHAIR-BARREL (LOUNGE)					
CHAIR-BARREL (LOUNGE)					
R&R (includes ped/base)	4060A	0.3	X	X	
R&I	4060B	0.2			
BASE LEVER-KNOB					
R&R	4062A	0.1			
BASE LEVER-SLIDE/SWIVEL					
R&R	4063A	0.1			
RESECURE	4063R	0.1			
CABLE					
R&R	4069A	0.3			
ADJUST	4069J	0.2			
COVER					
R&R (INCLUDES R&R OF CHAIR)	4064A	ST	X	X	
REPAIR, SEW	4064C	0.3			
FOAM					
R&R (includes R&R chair&cover)	4065A	ST	X	X	
FRAME					
R&R	4066A	ST	X	X	
PEDESTAL					
R&R (includes R&R of chair)	4067A	0.4			
REMOTE CONTROL COVER					
R&R	4073A	0.1			
SIDES					
R&R	4068A	0.2			
*CHAIR-DINETTE (FREESTANDING)					
CHAIR- FREESTANDING (WOOD/METAL)					
R&R	4015A	0.1	X	X	
REPAIR	4015C	0.3			
CHAIR-SWIVEL ROCKER					
SWIVEL ROCKER					
R&R COMPLETE	4240A	0.1	X	X	
BUTTON (PRONGS)					
R&R EACH	4241A	1.2	X	X	
COVER					
R&R SEAT	4242A	1.2	X	X	
R&R BACK/ARMS	4243A	1.5	X	X	
FOAM					
R&R SEAT	4244A	1.0	X	X	
R&R BACK	4245A	0.8	X	X	
FRAME					
R&R	4246A	2.0	X	X	
PEDESTAL					
R&R	4247A	0.2			



SOFT GOODS

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>FURNITURE (CONT.)</u>					
*CHAIR-WALL HUGGER					
WALL HUGGER					
R&R	4285A	0.1	X	X	
COVER					
REPAIR	4286C	0.3	X		
FRAME					
REPAIR	4287C	0.3	X		
*CUSHION-CABOVER					
CABOVER CUSHION					
R&R	4080A	0.1	X	X	
COVER					
R&R	4081A	0.9	X	X	
FOAM					
R&R	4082A	0.9	X	X	
INSERT					
R&R	4083A	0.1	X	X	
CUSHION-DINETTE					
CUSHION-DINETTE					
R&R	4070A	0.1	X	X	
COVER (INCLUDES SEAT & BACK)					
R&R	4071A	0.5	X	X	
REPAIR, SEW	4071C	0.3			
FOAM					
R&R	4072A	0.5	X	X	
*PILOT SEAT					
PILOT SEAT					
R&R	4180A	0.3	X	X	
R&I	4180B	0.3			
ARM REST					
R&R	4181A	0.3	X	X	
REPAIR	4181C	0.3			
BASE (PEDESTAL)					
R&R (includes R&I pilot seat)	4182A	0.5			
REPAIR	4182C	0.3			
WELD	4182W	0.3			
CABLE					
R&R	4198A	0.3			
ADJUST	4198J	0.2			
COVER-ARM SEAT					
R&R	4183A	0.2	X		
REPAIR, SEW	4183C	0.2			
COVER-SEAT & BACK					
R&R	4184A	1.5	X	X	
REPAIR, SEW	4184C	0.3			
COVER-SEAT OR BACK					
R&R	4185A	1.0	X	X	
REPAIR, SEW	4185C	0.3			



SOFT GOODS

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>FURNITURE (CONT.)</u>					
*PILOT SEAT (CONT.)					
6-WAY POWER UNIT					
R&R (includes R&I pilot seat)	4186A	1.1	X		X
GEAR					
R&R (includes R&I pilot seat)	4187A	1.3			
HARNESS R&R	4188A	0.2			
INTEGRATED SEAT BELT					
R&R	4335A	3.0	X		X
REPAIR	4335C	0.3			
MOTOR (6-WAY POWER UNIT)					
R&R (includes R&I pilot seat)	4189A	1.3			X
SWITCH ASSEMBLY					
R&R	4190A	0.2			
FOAM R&R	4191A	1.5	X		X
FRAME					
R&R	4192A	1.5	X		X
REPAIR	4192C	0.3			
WELD	4192W	0.3			
REMOTE CONTROL COVER					
R&R	4199A	0.1			
RECLINER HANDLE					
R&R	4193A	0.1			
RECLINER MECHANISM					
REPAIR	4194C	0.3			
SLIDER HANDLE					
R&R	4195A	0.1			
KNOB-SLIDER					
R&R	4196A	0.1			
MECHANISM-SLIDER (PAIR)					
R&R	4197A	0.6			
REPAIR	4197C	0.2			
RESECURE	4197R	0.1			
FOOT REST MOTOR	4336A	0.3			X
*SOFA – METAL FRAME JACKKNIFE					
SOFA (METAL FRAME JACKKNIFE)					
R&R	4210A	0.5	X		X
R&I	4210B	0.5			
RESECURE	4210R	0.3			
ARM (PRE-UPHOLSTERED)					
R&R	4211A	0.3	X		X
RESECURE	4211R	0.3			
COVER (SEAT OR BACK)					
R&R	4213A	2.0	X		X
REPAIR, SEW	4213C	0.3			
FOAM R&R (includes R&R sofa/cover)	4214A	2.0	X		X
FRAME – BASE					
R&R (includes R&R sofa/cover)	4212A	1.0			
REPAIR	4212C	1.0			



SOFT GOODS

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>FURNITURE (CONT.)</u>					
*SOFA METAL FRAME JACKKNIFE (CONT.)					
FRAME (SEAT OR BACK)					
R&R (includes R&R sofa/cover)	4215A	2.0			
REPAIR	4215C	0.3			
WELD	4215W	0.3			
KICKBOARD R&R	4217A	0.2	X		X
SEAT OR BACK ASSEMBLY					
R&R	4219A	0.2	X		X
*SOFA HIDE-A-BED					
SOFA-HIDE-A-BED					
R&R COMPLETE	4320A	0.5	X		X
R&I	4320B	0.5			
REPAIR	4320C	ST			
RESECURE	4320R	0.5			
ARM R&R	4321A	0.1	X		
FRAME R&R	4322A	2.0	X		X
WELD	4322W	1.5	X		
COVER R&R	4323A	2.0	X		X
REPAIR, SEW	4323C	0.3			
CUSHION BACK					
R&R (EACH SECTION)	4326A	1.0	X		X
FOAM R&R (SEAT SECTION)	4324A	0.3	X		X
MATTRESS					
R&R	4325A	0.2	X		X
AIR MATTRESS BLADDER					
R&R	4328A	0.2			X
AIR MATTRESS PUMP					
R&R	4329A	0.1			X
STOOL					
STOOL-BAR					
R&R	4016A	0.1	X		X
<u>TREATMENTS</u>					
BEDSPREAD					
R&R	4010A	0.1	X		X
BOLSTER/HEADBOARD					
BOLSTER/ HEADBOARD (FABRIC)					
R&R	4020A	0.2	X		
R&I	4020B	0.2			
REPAIR	4020C	0.2			
CURTAIN/DRAPERIES					
CURTAINS-EACH WINDOW(PAIR)					
R&R (INCLUDES R&R TIE BACKS)	4100A	0.2	X		X
REPAIR, SEW IN PLACE	4100C	0.2			
CURTAIN TRACK					
R&R	3298A	0.2			
R&I	3298B	0.1			
RELOCATE	3298F	0.1			



SOFT GOODS

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>TREATMENTS (CONT.)</u>					
CURTAINS/DRAPERIES					
ROOM PRIVACY					
R&R	4090A	0.2	X	X	
REPAIR, SEW	4090C	0.2			
SHOWER R&R	4092A	0.2			
TIE BACKS (PAIR)					
R&R	4101A	0.1			
REPAIR, SEW	4101C	0.2			
WINDSHIELD PRIVACY					
R&R	4093A	0.3	X	X	
REPAIR, SEW IN PLACE	4093C	0.2			
ROLLERS-COMplete SET					
R&R (INCLUDES R&R CURTAIN)	4094A	0.5			
TRACK					
R&R (INCLUDES R&R CURTAIN & ROLLERS)	4095A	0.4			
R&I (INCLUDES R&I CURTAIN & ROLLERS)	4095B	0.4			
RESECURE	4095R	0.2			
HEADKNOCKER					
HEADKNOCKER					
R&R	4110A	0.1	X		
R&I	4110B	0.1			
REPAIR, SEW	4110C	0.1			
LAMBREQUIN-SHADOW BOX					
DRAPE PANEL (FABRIC LAMBREQUIN)					
R&R PANEL	4121A	0.1	X		
LAMBREQUIN-SHADOW BOX					
R&R	4120A	0.2	X		
R&I	4120B	0.1			
ADJUST (IN PLACE)	4120J	0.1			
MATTRESS					
BUNK BED R&R					
BUNK BED COVER	4134A	0.1	X	X	
R&R	4135A	0.1	X	X	
DOUBLE BED					
R&R	4130A	0.1	X		
REPAIR, SEW	4130C	0.3			
TWIN BED					
R&R	4131A	0.1	X		
REPAIR, SEW	4131C	0.3			
OVERHEAD BUNK					
R&R	4132A	0.1	X		
REPAIR, SEW	4132C	0.3			
QUEEN					
R&R	4133A	0.2	X		
R&I	4133B	0.2			
REPAIR, SEW	4133C	0.4			



SOFT GOODS

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>TREATMENTS (CONT.)</u>					
SHADE					
ROLLER SHADE					
R&R	4200A	0.1	X		X
R&I	4200B	0.1			
ROLLER TUBE					
R&R	4202A	0.2			X
ADJUST	4202J	0.1			
BRACKET					
R&R	4201A	0.1			
PLEATED SHADE					
R&R	4203A	0.2	X		X
R&I	4203B	0.2			
ADJUST	4203J	0.2			
SUNSCREEN SHADE					
R&R	4205A	0.2	X		X
SPARE TIRE COVER-VINYL					
SPARE TIRE COVER-VINYL					
R&R	4230A	0.1			
SPEAKER CLOTH					
SPEAKER CLOTH					
R&R	4235A	0.2			
REPAIR	4235C	0.2			
VALANCE					
VALANCE					
R&R	4260A	0.2	X		
R&I	4260B	0.1			
ADJUST (IN PLACE)	4260J	0.1			
VENETIAN BLIND					
VENETIAN BLIND					
R&R	4270A	0.2			
R&I	4270B	0.2			
ADJUST	4270J	0.1			
MECHANISM					
R&R	4273A	0.4			
SLAT					
R&R	4272A	0.3			
SLAT ADJUST WAND					
R&R (1-5 pcs.)	4271A	0.1			
BRACKETS					
R&R (PER BLIND)	4275A	0.1			
ADJUST (PER BLIND)	4275J	0.1			
VERTICAL BLIND					
VERTICAL BLIND					
R&R	4274A	0.4	X		X



SOFT GOODS

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>TREATMENTS (CONT.)</u>					
TRIM PADS					
A-PILLAR					
R&R	4151A	0.2			
R&I	4151B	0.2			
REPAIR	4151C	0.2			
B-PILLAR (MINI)					
R&R	4163A	2.0	X		
REPAIR	4163C	0.3			
HEADLINER (MINI)					
R&R	4164A	2.0	X		
REPAIR	4164C	0.3			
PADDED TRIM					
R&R (DINETTE SEAT BACK)	4160A	0.2			
R&R (DINETTE END)	4161A	0.2			
R&R (CABOVER-MINI)	4162A	0.2			
REPAIR (ALL)	4160C	0.3			



WATER SYSTEM

ABOUT THIS SECTION:

ALL LABOR ALLOWANCES INCLUDE ACCESS, DIAGNOSIS, REMOVE AND REINSTALL OF COMPONENTS, SET-UP, AND TESTING UNLESS OTHERWISE INDICATED.

WHERE AN ASTERISK (*) IS INDICATED, A PRESSURE TEST OF THE FRESH WATER SYSTEM MUST BE DONE AFTER THE REPAIR IS COMPLETED. AN ALLOWANCE OF THIS SECTION CAN BE CLAIMED FOR A PRESSURE TEST ONCE PER SYSTEM REPAIR.

WHERE A POUND SIGN (#) IS INDICATED, PLEASE RETURN ONLY THE DEFECTIVE PORTION OF THE COMPONENT FOR WARRANTY CONSIDERATION.

COMPONENTS

- ABS DRAIN LINES & COMPONENTS
- FRESH WATER PRESSURE TEST
- FAUCETS
- HOLDING TANKS
- OUTSIDE SHOWER
- SHOWER DOORS
- SHOWER ENCLOSURE (GLASS)
- SHOWER HEAD/HOSE
- SHOWER PAN
- SHOWER STALL-FIBERGLASS
- SINKS
- TERMINATION VALVE
- TOILETS
- WATER FILLS
- WATER CONTROL PANEL
- WATER HEATER
- WATER LINES & FITTINGS
- WATER PUMPS



WATER SYSTEM

<u>OPERATION</u>	<u>OPERATION NUMBER</u>	<u>TIME</u>	<u>APPROVAL REQUIRED</u>	<u>RETURN PART</u>	<u>MODEL#, SERIAL # REQUIRED</u>
<u>ABS DRAIN LINES & COMPONENTS</u>					
NOTE: THE REPAIR OF SOME ABS DRAIN LINES OR COMPONENTS WILL REQUIRE THE REMOVAL OF OTHER COMPONENTS. THIS WILL REQUIRE THE USE OF OPERATION NUMBERS AND TIMES TO REMOVE AND REINSTALL THE APPLICABLE COMPONENT.					
DRAIN LINE 1-1/2"					
R&R	5010A	0.3			
SEAL IN PLACE	5010S	0.1			
DRAIN LINE 3"					
R&R	5012A	0.3			
SEAL IN PLACE	5012S	0.1			
DRAIN LINE SUPPORT HANGER					
R&R	5300A	0.2			
INSTALL	5300I	0.2			
RELOCATE	5300F	0.1			
FLEXIBLE DRAIN LINE (KITCHEN SLIDE OUT)					
R&R	5301A	ST			
RELOCATE	5301F	ST			
FITTING 3"					
R&R	5011A	0.2			
SEAL IN PLACE	5011S	0.1			
P-TRAP BATH SINK					
R&R	5014A	0.2			
TIGHTEN	5014S	0.1			
P-TRAP BATH TUB					
R&R	5015A	0.3			
TIGHTEN	5015S	0.2			
P-TRAP KITCHEN SINK					
R&R	5016A	0.2			
TIGHTEN	5016S	0.1			
P-TRAP WASHING MACHINE					
R&R	5019A	0.3			
TIGHTEN	5019S	0.1			
ROOF VENT PIPE					
R&R (EACH SECTION)	5017A	0.5			
SEAL AT TANK	5017S	ST			
TERMINATION SYSTEM (NO MESS)					
R&R	5302A	0.5			
REPAIR	5302C	0.3			
VENT CHECK					
R&R	5018A	0.3			
<u>FRESH WATER PRESSURE TEST</u>					
FRESH WATER PRESSURE TEST	5000T	0.2			
<u>FAUCETS</u>					
BATHROOM					
*R&R	5020A	0.3			X
*R&I	5020B	0.3			



WATER SYSTEM

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>FAUCETS (CONT.)</u>					
BATHTUB					
*R&R	5021A	0.3		X	
*R&I	5021B	0.3			
OUTSIDE SHOWER					
*R&R	5025A	0.3		X	
*R&I	5025B	0.3			
KITCHEN					
*R&R	5022A	0.3		X	
*R&I	5022B	0.3			
HAND SPRAYER					
R&R	5026A	0.1		X	
*STEM AND BONNET/ CARTRIDGE					
R&R	5023A	0.2			
*CARTRIDGE WASHER/O-RING					
R&R (IN PLACE)	5024A	0.2			
SPOUT R&R	5027A	0.1			
HANDLES R&R	5028A	0.2			
AERATOR R&R	5029A	0.1			
<u>HOLDING TANKS</u>					
BLACK WATER					
BLACK WATER					
#R&R	5031A	ST		X	
R&I	5031B	ST			
REPAIR (ALL TYPES)	5031C	0.3			
SEAL (INLET OR OUTLET)	5031S	0.2			
SUPPORT					
R&R	5033A	0.3			
WELL NUT (TANK PROBE)					
INSTALL	5032I	0.2			
CHECK VALVE (FLUSH SYSTEM)					
R&R	5037A	0.2			
SPRAY FITTING (FLUSH SYSTEM)					
R&I	5038A	0.5			
FRESH WATER					
BASEMENT INSTALLATION					
#R&R-CLASS A	5258A	2.5		X	
#R&R-CLASS C	5259A	3.0		X	
REPAIR (ALL TYPES)	5250C	0.5			
SHROUD					
R&R	5251A	0.4			
R&I	5251B	0.4			
STANDARD MOUNTING					
#R&R	5252A	1.5		X	
R&I	5252B	1.5			
UNDERMOUNT					
#R&R	5255A	2.5		X	
R&I	5255B	2.5			



WATER SYSTEM

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>HOLDING TANKS (CONT.)</u>					
FRESH WATER (CONT.)					
SUPPORT					
R&R	5257A	0.3			
WELL NUT (TANK PROBE)					
INSTALL	5256I	0.2			
GREY WATER					
GREY WATER					
#R&R	5030A	ST		X	
R&I	5030B	ST			
REPAIR (ALL TYPES)	5030C	0.3			
SEAL (INLET OR OUTLET)	5030S	0.2			
SUPPORT					
R&R	5033A	0.3			
WELL NUT (TANK PROBE)					
INSTALL	5032I	0.2			
<u>OUTSIDE SHOWER</u>					
*OUTSIDE SHOWER					
R&R	5060A	0.3		X	
R&I	5060B	0.3			
SEAL	5060D	0.3			
CAP SEAL	5060S	0.1			
OUTSIDE SHOWER DOOR					
R&R	5062A	0.1			
OUTSIDE SHOWER LATCH					
R&R	5061A	0.1			
<u>SHOWER DOORS</u>					
BI-FOLD DOOR					
BI-FOLD					
R&R (COMPLETE)	5120A	0.7			
R&I	5120B	0.7			
HANDLE R&R	5121A	0.2			
LATCH R&R	5122A	0.2			
TRACK (SIDES OR BOTTOM)					
R&R	5123A	0.2			
TRACK (UPPER)					
R&R	5124A	0.3			
PLEATED DOOR					
PLEATED DOOR					
R&R (COMPLETE)	5155A	0.4			
TRACK (SIDES OR BOTTOM)					
R&R	5156A	0.2			
TRACK-TOP	5157A	0.2			
SLIDING GLASS SHOWER DOOR					
SLIDING GLASS DOOR					
R&R	5195A	0.5			
TRACK R&R	5196A	0.3			



WATER SYSTEM

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>SHOWER ENCLOSURE-GLASS</u>					
FIXED PANEL					
R&R	5125A	0.8	X		
R&I	5125B	0.8			
SEAL	5125S	0.3			
DOOR R&R	5126A	0.2	X		
DOOR HANDLE					
R&R	5127A	0.2			
DOOR LATCH					
R&R	5128A	0.2			
DOOR SEAL					
R&R	5129A	0.2			
<u>SHOWER HEAD/HOSE</u>					
SHOWER HEAD					
R&R	5080A	0.1			
SHOWER HOSE					
R&R	5090A	0.1			
SHOWER HOSE ANTI-SIPHON DEVICE					
R&R	5091A	0.1			
SHOWER HEAD/HOSE HOLDER OR GUIDE					
R&R	5092A	0.1			
R&I	5092B	0.1			
<u>SHOWER PAN</u>					
SHOWER PAN					
#R&R	5100A	0.5		X	
R&I	5100B	0.5			
REPAIR (W/O REMOVAL)	5100C	0.4			
SEAL IN PLACE	5100S	0.1			
<u>SHOWER STALL (FIBERGLASS)</u>					
SHOWER STALL					
REPAIR	5166C	ST	X		
<u>SINKS</u>					
BATH SINK DRAIN BASKET					
R&R	5113A	0.2			
SEAL	5113S	0.2			
BATHROOM VANITY					
*R&R	5110A	0.3			
*R&I	5110B	0.3			
SEAL IN PLACE	5110S	0.1			
KITCHEN					
*R&R	5111A	0.6			
*R&I	5111B	0.6			
SEAL IN PLACE	5111S	0.1			
KITCHEN SINK DRAIN BASKET					
R&R	5112A	0.2			
SEAL	5112S	0.2			



WATER SYSTEM

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>TERMINATION VALVE</u>					
EXTENSION ROD					
R&R	5041A	0.2			
HANDLE R&R	5042A	0.1			
SEALS R&R	5043A	0.5			
TERMINATION CAP					
R&R	5044A	0.1			
<u>TOILETS</u>					
TOILET					
*R&R	5130A	0.5	X		X
*R&I	5130B	0.5			
*BALL VALVE					
R&R	5131A	0.8			X
*SLIDE VALVE					
R&R	5132A	1.0			X
*SEAL RING (FLOOR MOUNT)					
R&R	5133A	0.6			X
SEAT AND COVER ASSEMBLY					
R&R	5134A	0.2			X
*VACUUM BREAKER					
R&R	5135A	1.0			X
*FLOOR FLANGE					
R&R	5137A	1.0			X
FLUSH TUBE					
R&R	5136A	0.7			X
<u>PORCELAIN</u>					
TOILET (PORCELAIN)					
*R&R	5260A	0.8	X	X	X
*R&I	5260B	0.8			
*BASE R&R	5261A	0.5			X
*BOWL R&R	5262A	0.5			X
*SEAL/FLOOR FLANGE					
R&R	5263A	1.0			X
SEAT & COVER					
R&R	5264A	0.2			X
*SPRING CARTRIDGE					
R&R	5265A	1.0			X
*VACUUM BREAKER					
R&R	5266A	0.8			X
*VALVE					
R&R	5267A	0.5			X
HANDSPRAYER					
R&R	5268A	0.1			X
<u>WATER FILLS</u>					
CITY WATER FILL					
*R&R	5200A	0.3			
*R&I	5200B	0.3			
SEAL IN PLACE	5200S	0.1			



WATER SYSTEM

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>WATER FILLS (CONT.)</u>					
GRAVITY WATER FILL					
R&R	5202A	0.3			
R&I	5202B	0.3			
SEAL IN PLACE	5202S	0.1			
*CHECK VALVE					
R&R	5201A	0.2			
CLAMP					
R&R	5203A	0.2			
RESECURE	5203R	0.1			
HOSE-VENT OR FILL					
R&R	5204A	0.2			
RESECURE	5204R	0.1			
<u>WATER CONTROL PANEL</u>					
WATER CONTROL PANEL					
*R&R	5065A	0.8			
*R&I	5065B	0.6			
<u>WATER LINES & FITTINGS</u>					
NOTE: THE REPAIR OF SOME WATER LINES & FITTINGS MAY REQUIRE THE REMOVAL OF OTHER COMPONENTS. THIS WILL REQUIRE THE USE OF OPERATION NUMBERS AND TIMES TO REMOVE AND REINSTALL THE APPLICABLE COMPONENT.					
*CHECK VALVE (WATER HEATER)					
R&R	5201A	0.2			
CRIMP RING					
*R&R	5213A	0.2			
RESECURE	5213R	0.1			
DRAIN LINE					
R&R	5216A	0.3			
*PRESSURE LINE					
R&R	5210A	0.4			
PRESSURE FITTING					
*R&R	5211A	0.3			
*TIGHTEN CONNECTION	5211Y	0.1			
SUCTION HOSE					
R&R	5212A	0.2			
*VALVE – DRAIN (POP-UP “T”)					
R&R	5214A	0.3			
*VALVE-SHUT OFF					
R&R	5215A	0.3			
<u>WATER PUMPS</u>					
NOTE: COMPLETE PUMP MUST BE REPLACED IN A WARRANTY REPAIR. CLAIMS FOR REPAIRING A WATER PUMP WILL NOT BE HONORED.					
ELECTRIC					
ELECTRIC WATER PUMP					
*R&R	5220A	0.5			X
*R&I	5220B	0.5			



LP GAS SYSTEM

ABOUT THIS SECTION:

ALL LABOR ALLOWANCES INCLUDE ACCESS, DIAGNOSIS, AND TESTING WITH A LEAK DETECTOR SOLUTION UNLESS OTHERWISE INDICATED.

REPAIRS TO THE LP GAS SYSTEM REQUIRE A DROP PRESSURE TEST OR TESTING WITH A LEAK DETECTOR SOLUTION. TESTS REQUIRED AS PART OF THE REPAIR AND ARE NOTED ON EACH PAGE BY OPERATION.

COMPONENT

- DROP PRESSURE TEST
- LP COMPONENT SUPPLY LINES
- LP FITTINGS
- HOSES
- ELECTRONIC LEAK DETECTOR
- MANIFOLD (MAIN SUPPLY)
- REGULATOR
- TANK UNDERMOUNT



LP GAS SYSTEM

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
-----------	---------------------	------	----------------------	-------------	------------------------------

CAUTION: AN ASTERISK (*) NEXT TO AN OPERATION INDICATES THAT A DROP PRESSURE TEST MUST BE PERFORMED FOLLOWING COMPLETION OF THE REPAIR. THIS OPERATION CAN BE USED ONCE PER SYSTEM REPAIR.

DROP PRESSURE TEST

DROP PRESSURE TEST	6200T	0.3
--------------------	-------	-----

(MUST UTILIZE MANOMETER OR U-TUBE GAUGE)

LP COMPONENT SUPPLY LINES-3/8"

NOTE: THE REPLACEMENT OF SOME LP LINES WILL REQUIRE THE REMOVAL OF OTHER COMPONENTS. THIS WILL REQUIRE THE USE OF OPERATION NUMBERS AND TIMES TO REMOVE AND REINSTALL THE APPLICABLE COMPONENT.

FURNACE

*SUPPLY LINE		
R&R	6010A	0.4
*FLARE REPAIR	6010C	0.3
*FLARE NUT		
LOCATE & TIGHTEN	6010Y	0.3
SUPPLY LINE		
RESECURE	6010R	0.1
*MANIFOLD FLARE NUT		
LOCATE & TIGHTEN	6015Y	0.3

RANGE

*SUPPLY LINE		
R&R	6011A	0.4
*FLARE REPAIR	6011C	0.3
*FLARE NUT		
LOCATE & TIGHTEN	6011Y	0.3
SUPPLY LINE		
RESECURE	6011R	0.1
*MANIFOLD FLARE NUT		
LOCATE & TIGHTEN	6016Y	0.3

REFRIGERATOR

*SUPPLY LINE		
R&R	6014A	0.4
*FLARE REPAIR	6012C	0.3
*FLARE NUT		
LOCATE & TIGHTEN	6012Y	0.3
SUPPLY LINE		
RESECURE	6012R	0.1
*MANIFOLD FLARE NUT		
LOCATE & TIGHTEN	6017Y	0.3

FLEXIBLE SUPPLY LINE (KITCHEN SIDE OUT)

SUPPLY LINE		
R&R	6014A	0.4
*FLARE REPAIR	6014C	0.3
*FLARE NUT		
LOCATE & TIGHTEN	6014Y	0.3
SUPPLY LINE		
RESECURE	6014R	0.1



LP GAS SYSTEM

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>LP COMPONENTS SUPPLY LINES – 3/8" (CONT.)</u>					
WATER HEATER					
*SUPPLY LINE					
R&R	6013A	0.4			
*FLARE REPAIR	6013C	0.3			
*FLARE NUT					
LOCATE & TIGHTEN	6013Y	0.3			
SUPPLY LINE					
RESECURE	6013R	0.1			
*MANIFOLD FLARE NUT					
LOCATE & TIGHTEN	6018Y	0.3			
<u>LP FITTINGS</u>					
SUPPLY TUBING CLAMP					
R&R	6020A	0.1			
*FITTING LP-GAS					
R&R	6030A	0.2			
*FLARE NUT					
R&R	6040A	0.3			
<u>HOSES</u>					
NOTE: REPAIRS TO HELP LP SYSTEM COMPONENTS MUST BE TESTED WITH A LEAK DETECTOR SOLUTION TO INSURE THE INTEGRITY OF THE SYSTEM. THE TIME TO PERFORM THIS TEST IS INCLUDED IN EACH TIME ALLOWANCE.					
HOSE-TANK TO REGULATOR					
*R&R	6060A	0.2			
*LOCATE & TIGHTEN	6060Y	0.2			
HOSE-REGULATOR TO MANIFOLD					
*R&R	6016A	0.2			
*LOCATE & TIGHTEN	6016Y	0.2			
<u>ELECTRONIC LEAK DETECTOR</u>					
LP LEAK DETECTOR (ELECTRONIC)					
R&R	6070A	0.2		X	
R&R	6070B	0.1			
<u>MANIFOLD – (MAIN SUPPLY)</u>					
*MANIFOLD TUBE					
R&R	6080A	0.3			
*FLARE – MANIFOLD TUBE					
REPAIR	6080C	0.3			
TIGHTEN	6080Y	0.3			
MANIFOLD TUBE					
RESECURE	6080R	0.1			
MANIFOLD TUBE CLAMP					
R7R	6090A	0.1			



LP GAS SYSTEM

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>REGULATOR</u>					
NOTE: MANUAL OR AUTOMATIC CHANGE OVER REQUIRES REPLACEMENT OF COMPLETE ASSEMBLY.					
NOTE: REPAIRS TO THIS LP SYSTEM COMPONENT MUST BE TESTED WITH LEAK DETECTOR SOLUTION TO INSURE THE INTEGRITY OF THE SYSTEM. THE TIME TO PERFORM THIS TEST IS INCLUDED IN EACH TIME ALLOWANCE.					
*REGULATOR- ALL TYPES					
R&R	6110A	0.3		X	
REGULATOR COVER					
R&R	6111A	0.1			
<u>TANK-UNDERMOUNT</u>					
NOTE: DO NOT ATTEMPT TO WELD OR REPAIR A LP TANK.					
TANK					
R&R	6120A	0.5	X	X	
R&I	6120B	0.5			
80% STOP FILL VALVE					
R&R	6121A	0.5		X	
RESEAL	6121S	0.5			
80% STOP FILL VALVE GASKET					
R&R	6122A	0.5		X	
20% BLEEDER VALVE					
R&R	6123A	0.5		X	
RESEAL	6123S	0.5			
ON/OFF VALVE					
R&R	6124A	0.5		X	
RESEAL	6124S	0.5			
SENDING UNIT					
R&R	6125A	0.5		X	
RESEAL	6125S	0.5			
SENDING UNIT GASKET					
R&R	6126A	0.5			
SIGHT GAUGE					
R&R	6127A	0.2		X	



ELECTRICAL

ABOUT THIS SECTION:

ALL LABOR ALLOWANCE INCLUDE ACCESS, DIAGNOSIS, REMOVE AND REINSTALL OF COMPONENTS, SET-UP, AND TESTING UNLESS OTHERWISE INDICATED.

COMPONENT

- BATTERY/BATTERY COMPONENTS
- CEILING FAN
- CIRCUIT BREAKERS
- CONDUIT
- DASH/COCKPIT COMPONENTS
- DEFROSTER FAN
- DIODE
- ENTERTAINMENT CENTER (OUTSIDE)
- FUSE HOLDER
- JUNCTION BOX
- LIGHTS
- MONITOR PANEL
- POWER CENTER
- POWER INVERTER
- RECEPTACLES
- RELAYS
- SERVICE (DISTRIBUTION) PANEL
- SHORE LINE CORD
- SPLITTER (TV)
- SOLENOID
- SWITCHES



ELECTRICAL

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>BATTERY/BATTERY COMPONENTS</u>					
<u>BATTERY</u>					
BATTERY DISCONNECT (ELECTRONIC)					
R&R	7055A	0.5		X	
R&I	7055B	0.1			
SOLENOID					
R&R	7056A	0.5		X	
BATTERY DISCONNECT (MANUAL)					
R&R	7058A	0.5		X	
BATTERY BOX					
R&R	7045A	0.2			
CABLE					
R&R	7040A	0.2			
RESECURE	7040R	0.1			
CABLE END					
R&R	7050A	0.2			
<u>CEILING FAN</u>					
R&R	7062A	0.5	X	X	
R&I	7062B	0.3			
<u>CIRCUIT BREAKERS</u>					
110V CIRCUIT BREAKER					
R&R (STANDARD)	7331A	0.2			
12V CIRCUIT BREAKERS					
R&R (AUTO RESET)	7081A	0.3			
R&R (MANUAL RESET)	7080A	0.3			
<u>CONDUIT</u>					
R&R	7345A	0.2			
<u>DASH/COCKPIT COMPONENTS</u>					
CIGARETTE LIGHTER					
R&R	7093A	0.1			
CIGARETTE LIGHTER SOCKET					
R&R	7094A	0.2			
CORNERING LIGHT MODULE					
R&R	7500A	0.5		X	
DAYTIME RUNNING LIGHT MODULE					
R&R	7501A	0.5		X	
DESTINY OVERHEAD PANEL					
R&R	7502A	ST	X	X	
TV LOCK-OUT RELAY	7524A	0.5		X	
<u>DEFROSTER FAN</u>					
R&R	7130A	0.3		X	
R&I	7130B	0.3			
DEFROSTER FAN SWITCH					
R&R	7131A	0.2			
<u>DIODE</u>					
R&R	7142A	0.3			



ELECTRICAL

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>ENTERTAINMENT CENTER – OUTSIDE</u>					
ENTERTAINMENT CENTER (OUTSIDE)					
R&R	7145A	0.5		X	
R&I	7145B	0.1			
REMOVE, SEAL, REINSTALL	7145D	0.3			
ENTERTAINMENT CENTER DOOR					
R&R	7146A	0.3			
ENTERTAINMENT LATCH					
R&R	7147A	0.1			
<u>FUSE HOLDER</u>					
FUSE HOLDER – IN LINE					
R&R	7180A	0.2			
<u>JUNCTION BOX</u>					
R&R – 12V	7165A	0.2			
R&R – 110V	7166A	0.3			
<u>LIGHTS</u>					
EXTERIOR LIGHTS					
BRAKE/TAIL LIGHT ASSEMBLY					
R&R	7202A	0.3			
R&I	7202B	0.3			
REMOVE, SEAL, REINSTALL	7202D	0.3			
CAP SEAL	7202S	0.1			
BRAKE TAIL LIGHT POD ASSEMBLY (AUTOMOTIVE STYLE)					
R&R	7541A	0.3			
R&I	7541B	0.3			
REMOVE, SEAL, REINSTALL	7541D	0.3			
CAP SEAL	7541S	0.1			
BRAKE/ TAIL LIGHT BACK UP LENS					
R&R	7203A	0.1			
CLEARANCE					
R&R	7204A	0.1			
R&I	7204B	0.1			
CAP SEAL	7204S	0.1			
CLEARANCE LIGHT LENS					
R&R	7205A	0.1			
CORNERING					
R&R	7229A	0.3			
DOCKING					
R&R	7400A	0.2			
R&I	7400B	0.2			
DRIVING					
R&R	7228A	0.3			
ENGINE COMPARTMENT					
R&R	7214A	0.1			
FOG					
R&R	7206A	0.3			
R&I	7206B	0.3			
BULB	7207A	0.3			



ELECTRICAL

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>LIGHTS (CONT.)</u>					
EXTERIOR LIGHTS (CONT.)					
HEADLIGHT POD ASSEMBLY (AUTOMOTIVE STYLE)					
R&R	7211A	0.3		X	
R&I	7211B	0.3			
ADJUST PER UNIT	7213J	0.5			
HEADLIGHT (SEALED BEAM)					
R&R	7213A	0.4			
LICENSE PLATE					
R&R	7227A	0.1			
MIRROR-TURN SIGNAL					
R&R (BULB)	7316A	0.1			
R&R (LENS)	7317A	0.1			
PORCH					
R&R	7218A	0.2			
R&I	7218B	0.2			
SEAL	7218S	0.1			
PORCH LIGHT LENS					
R&R	7219A	0.1			
SECURITY LIGHT					
R&R	7490A	0.3			
R&I	7490B	0.3			
HITCH LIGHT					
R&R	7491A	0.3			
R&I	7491B	0.3			
STEP LIGHT					
R&R	7314A	0.1			
STORAGE COMPARTMENT					
R&R	7223A	0.2			
TURN SIGNAL LIGHT-FRONT					
R&R	7225A	0.3			
R&I	7225B	0.3			
TURN SIGNAL LENS					
R&R	7226A	0.3			
INTERIOR LIGHTS					
AISLE R&R	7230A	0.1			
COMBINATION 12V/110V					
R&R	7505A	0.2		X	
DECORATOR (CEILING)					
R&R	7232A	0.2		X	
FLUORESCENT					
R&R	7233A	0.2		X	
HALOGEN					
R&R	7508A	0.1			
HANGING LIGHT					
R&R	7527A	0.2		X	
R&I	7527B	0.1			



ELECTRICAL

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>LIGHTS (CONT.)</u>					
INTERIOR LIGHTS (CONT.)					
INDIRECT (BEAD)					
R&R SECTION	7231A	0.2			
R&I SECTION	7231B	0.2			
MAKE-UP (BAR)					
R&R	7525A	0.2			
PANCAKE					
R&R	7236A	0.2			
PANCAKE LIGHT LENS					
R&R (1-5 LENSES)	7243A	0.1			
READING (AIRCRAFT)					
R&R	7237A	0.2			
STRIP LIGHT					
R&R	7126A	0.5		X	
STRIP LIGHT INVERTER					
R&R	7127A	0.5		X	
TABLE LAMP (12V,110V)					
R&R	7238A	0.2		X	
TABLE LAMP SHADE					
R&R	7239A	0.1			
WALL LAMP (12V,110V)					
R&R	7240A	0.2		X	
WALL LAMP SHADE					
R&R	7241A	0.1			
WALL LAMP GLOBE (GLASS/PLASTIC)					
R&R	7493A	0.1			
<u>MONITOR PANEL</u>					
NOTE: DO NOT ATTEMPT REPAIRS TO PRINTED CIRCUIT BOARD UNDER WARRANTY.					
K-SERIES MONITOR PANELS REQUIRE REPLACEMENT OF THE INDIVIDUAL COMPONENTS.					
ALL LABOR ALLOWANCES INCLUDE DIAGNOSIS.					
FLUSHING OF TANKS IS CONSIDERED MAINTENANCE AND IS NOT WARRANTABLE.					
MONITOR PANEL					
R&R	7250A	0.2	X		X
R&I	7250B	0.2			
CIRCUIT BOARD					
R&R	7257A	0.2			X
FACE PLATE					
R&R	7259A	0.4			X
GENERATOR REMOTE START SWITCH					
R&R	7252A	0.2			X
GENERATOR HOUR METER					
R&R	7253A	0.2			X
LED (PUMP AND WATER HEATER INDICATOR)					
R&R	7258A	0.3			X



ELECTRICAL

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>MONITOR PANEL (CONT.)</u>					
SWITCH					
R&R	7255A	0.2		X	
TRANSMITTER (PIGTAIL AT TANK)					
R&R	7256A	0.2		X	
<u>POWER CENTER</u>					
NOTE: DO NOT MAKE REPAIRS TO THE CHARGER SECTION. REPLACEMENT OF THE COMPONENT IS REQUIRED FOR WARRANTY					
CONSIDERATION.					
POWER CONVERTER (FLOOR MOUNT)					
R&R	7275A	0.4		X	
R&I	7275B	0.4			
POWER CENTER (WALL MOUNT)					
R&R	7270A	0.8	X	X	
R&I	7270B	0.8			
CONVERTER/CHARGER MODULE					
R&R	7280A	0.8		X	
R&I	7280B	0.8			
CIRCUIT BREAKER-110V					
R&R	7271A	0.2			
DOOR LATCH					
R&R	7274A	0.1			
FUSE PANEL					
R&R	7281A	0.3			
DISTRIBUTION PANEL					
R&R	7287A	0.5			
DOOR R&R	7286A	0.1			
TRANSFER SWITCH					
POWER CENTER/ DISTRIBUTION CENTER MOUNT					
R&R	7273A	0.8		X	
NON-POWER CENTER MOUNT					
R&R	7010A	0.5		X	
NON-POWER CENTER MOUNT-CIRCUIT BOARD					
R&R	7012A	0.3		X	
<u>POWER INVERTER</u>					
R&R	7282A	2.0	X	X	
<u>RECEPTACLES</u>					
CABLE/PHONE JACK					
R&R	7315A	0.2			
R&R	7315B	0.2			
110V RECEPTACLE					
R&R	7313A	0.2			
R&R (BOX)	7311A	0.2			
R&R (COVER)	7312A	0.1			
110V GFI RECEPTACLE					
R&R	7310A	0.2		X	
R&R (COVER)	7311A	0.2			



ELECTRICAL

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>RECEPTACLES (CONT.)</u>					
12V RECEPTACLE					
R&R	7300A	0.2			
R&I	7300B	0.2			
R&R (BOX)	7301A	0.2			
50 AMP SHORELINE RECEPTACLES					
R&R	7318A	0.4			
R&I	7318B	0.2			
REMOVE, SEAL, REINSTALL	7318D	0.2			
7-WAY RECEPTACLE					
R&R	7319A	0.3			
<u>RELAYS</u>					
12V RELAYS					
R&R (AUTO RESET)	7534A	0.3			
R&R (MANUAL RESET)	7535A	0.3			
TV LOCK-OUT RELAY					
R&R	7524A	0.5		X	
<u>SERVICE (DISTRUBUTION) PANEL</u>					
R&R (ASSEMBLY)	7330A	0.7			
R&R (CIRCUIT BREAKER)	7331A	0.2			
<u>SHORE LINE CORD</u>					
SHORE LINE CORD					
R&R	7340A	0.5		X	
SLIDE OUT					
R&R	7356A	0.3		X	
50 AMP SHORELINE (DETACHABLE)					
R&R	7341A	0.1		X	
SHORE LINE WITH POWER REEL					
R&R	7342A	0.5	X	X	
<u>SOLENOID</u>					
DUAL BATTERY/EMERGENCY START					
R&R	7140A	0.5		X	
STEP COVER					
R&R	7355A	0.5			
SLIDE OUT SYSTEM					
R&R	7356A	0.3		X	
<u>SWITCHES</u>					
DASH/COCKPIT SWITCHES					
BLOCK HEATER (REAR DIESEL)					
R&R	7132A	0.2			
COURTESY FLASH (ICC)					
R&R	7095A	0.2			
DEFROSTER FAN					
R&R	7131A	0.2			
DOCKING LIGHT					
R&R	7114A	0.2			
DRIVING LIGHT					
R&R	7134A	0.2			



ELECTRICAL

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>SWITCHES (CONT.)</u>					
DASH/COCKPIT SWITCHES (CONT.)					
EXTERIOR MIRROR HEATER					
R&R	7097A	0.2			
EXTERIOR MIRROR DIRECTIONAL					
R&R	2046A	0.3		X	
EMERGENCY START					
R&R	7098A	0.2			
EXHAUST BRAKE					
R&R	7509A	0.2			
GENERATOR REMOTE START					
R&R	7100A	0.2		X	
HORN R&R	7090A	0.2			
INDIRECT LIGHT					
R&R	7511A	0.2			
MAP LIGHT					
R&R	7115A	0.2			
MONITOR PANEL					
R&R	7512A	0.2			
PORCH LIGHT					
R&R	7513A	0.2			
POWER STEP					
R&R	7514A	0.2			
RADIO ON/OFF					
R&R	7118A	0.2			
STEP COVER					
R&R	7515A	0.2			
STORAGE COMPARTMENT LIGHT					
R&R	7224A	0.2			
WATER PUMP					
R&R	7517A	0.2			
WATER HEATER (12V)					
R&R	7124A	0.2			
WINDSHIELD WASHER & WIPER					
R&R	7125A	0.2		X	
12 RECEPT	7136A	0.2			
12V SWITCHES- COACH					
DIMMER SWITCH					
R&R	7540A	0.2		X	
DOCKING LIGHT					
R&R	7114A	0.2			
GENERATOR REMOTE START					
R&R	7100A	0.2			
INDIRECT LIGHT					
R&R	7511A	0.2			
MONITOR PANEL					
R&R	7255A	0.2		X	
PORCH LIGHT					
R&R	7513A	0.2			



ELECTRICAL

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>SWITCHES (CONT.)</u>					
12V SWITCHES – COACH (CONT.)					
POWER STEP					
R&R	7514A	0.2			
STORAGE COMPARTMENT LIGHT					
R&R	7224A	0.2			
WATER HEATER					
R&R	8284A	0.2			
WATER PUMP					
R&R	7517A	0.2			
12V LIGHT SWITCH					
R&R	7523A	0.2			
110V SWITCHES					
CEILING FAN					
R&R	7532A	0.3			
TRANSFER SWITCH-AUTOMATIC-POWER CENTER MOUNT					
R&R	7273A	0.8		X	
TRANSFER SWITCH-AUTOMATIC-NON- POWER CENTER MOUNT					
R&R	7010A	0.5		X	
WATER HEATER					
R&R	7533A	0.3			



APPLIANCES

ABOUT THIS SECTION:

ALL LABOR ALLOWANCES INCLUDE ACCESS, DIAGNOSIS, REMOVE AND REINSTALL OF COMPONENTS, SET -UP, AND TESTING UNLESS OTHERWISE NOTED.

MODEL AND SERIAL NUMBER OF ALL APPLIANCES ARE REQUIRED ON THE WARRANTY CLAIM.

COMPONENTS

- AIR CONDITIONERS – ROOF MOUNT
- COFFEE MAKER
- DUCTING
- FURNACES
- MICROWAVE OVEN
- OVEN/RANGE
- RANGE HOOD
- REFRIGERATORS
- REMOTE CONTROL
- TELEVISION
- VACUUM CLEANER
- WASHER/DRYER
- WATER HEATER



APPLIANCES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
IMPORTANT NOTES:					
ALL LABOR ALLOWANCES INCLUDE DIAGNOSIS AND SET-UP.					
MODEL AND SERIAL NUMBER OF ALL APPLIANCES ARE REQUIRED ON THE WARRANTY CLAIM.					
<u>AIR CONDITIONER – ROOF MOUNT</u>					
DUOTHERM / DOMETIC					
AIR CONDITIONER					
R&I (INCLUDES GASKET REPLACEMENT)					
	8300B	0.5			X
AIR CONDITIONER GASKET					
R&R	8300S	0.5			X
CAPACITOR – FAN					
R&R	8316A	0.5			X
CAPACITOR – RUN					
R&R	8320A	0.5		X	X
CAPACITOR – START RELAY					
R&R	8304A	0.5		X	X
COMPRESSOR					
R&R	8305A	3.5		X	X
CONDENSER FAN BLADE/WHEEL					
R&R	8306A	0.7			X
CONDENSER MOTOR					
R&R	8311A	1.3		X	X
EVAPORATOR BLOWER WHEEL					
R&R	8307A	1.2			X
FILTER DRIER					
R&R	8321A	2.5	X	X	X
INNER SHROUD					
R&R	8313A	0.3			X
R&I	8313B	0.2			
MODULE BOARD – MAIN					
R&R	8317A	0.8		X	X
OUTER SHROUD					
R&R	8314A	0.3			X
SELECTOR SWITCH					
R&R	8312A	0.5			X
THERMOSTAT					
R&R	8315A	0.5		X	X
THERMASTAT – WALL					
R&R	8319A	0.5		X	X
R&I	8319B	0.1			
<u>COFFEE MAKER</u>					
R&R	8030A	0.2	X	X	X
R&I	8030B	0.2			



APPLIANCES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>DUCTING</u>					
DUCTING – RECTANGULAR (UNDER FLOOR)					
R&R	8294A	ST			
REPAIR	8294C	ST			
INSULATION – RECTANGULAR DUCT					
R&R	8296A	ST			
RESEAL OR TAPE	8296S	0.5			
DUCTING – ROUND FLEXIBLE-2" OR 4"					
R&R	8290A	0.2			
RESECURE	8290R	0.1			
FLOOR REGISTER					
R&R	8292A	0.1			
PLENUM – FLOOR					
R&R	8293A	0.5			
RESEAL OR TAPE	8293S	0.5			
PLENUM – FURNACE DISCHARGE					
R&R	8295A	0.8			
RESEAL OR TAPE	8295S	0.5			
PLENUM – ROOF					
RESEAL OR TAPE	8297S	0.5			
REPAIR	8297C	0.2			
ROTAIRE – 2" OR 4" – FURNACE					
R&R	8291A	0.1			
ROTAIRE – ROOF A/C					
R&R	8298A	0.1			
<u>FURNACES</u>					
HYDROFLAME/ATWOOD					
IMPORTANT NOTES:					
DROP PRESSURE TEST MUST BE PERFORMED UPON COMPLETION OF ANY REPAIRS INVOLVING THE LP GAS SYSTEM. FOLLOW RECOMMENDED SAFETY PROCEDURES AT ALL TIMES.					
OPERATIONS ARE FOR THE ACTUAL COMPONENT REPLACEMENT TIMES SUPPLIED BY THE MANUFACTURED. MOST REPAIRS <u>DONOT</u> REQUIRE FURNACE REMOVAL FROM THE UNIT. AN ALLOWANCE OF 0.4 (OPERATION 8050T) MAY BE CLAIMED FOR SET-UP TIME. THIS TIME INCLUDES SET-UP FOR THE REPAIR AND TESTING THE LP SYSTEM. SET-UP TIME CAN ONLY BE USED <u>ONCE</u> PER REPAIR.					
NOTE: LD FURNACES ONLY -ALLOWS 8050B (R&I) IN ADDITION TO 8050T (SET-UP) AND COMPONENT REPLACEMENT TIME.					
SET – UP	8050T	0.4			X
FURNACE R&I	8050B	0.5			X
AIRWHEEL (CIRCULATING)					
R&R	8052A	0.4		X	X
AIRWHEEL (COMBUSTION)					
R&R	8054A	0.6		X	X
BURNER					
R&R	8066A	0.2		X	X
CIRCUIT BREAKER					
R&R	8068A	0.1		X	X
COMBUSTION CHAMBER					
R&R	8067A	1.1		X	X
DOOR R&R (NO SET UP)	8088A	0.1			X



APPLIANCES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
-----------	---------------------	------	----------------------	-------------	------------------------------

FURNACES

HYDROFLAME/ATWOOD

IMPORTANT NOTES:

DROP PRESSURE TEST MUST BE PERFORMED UPON COMPLETION OF ANY REPAIRS INVOLVING THE LP GAS SYSTEM. FOLLOW RECOMMENDED SAFETY PROCEDURES AT ALL TIMES.

OPERATIONS ARE FOR THE ACTUAL COMPONENT REPLACEMENT TIMES SUPPLIED BY THE MANUFACTURED. MOST REPAIRS DONOT REQUIRE FURNACE REMOVAL FROM THE UNIT. AN ALLOWANCE OF 0.4 (OPERATION 8050T) MAY BE CLAIMED FOR SET-UP TIME. THIS TIME INCLUDES SET-UP FOR THE REPAIR AND TESTING THE LP SYSTEM. SET-UP TIME CAN ONLY BE USED ONCE PER REPAIR.

NOTE: LD FURNACES ONLY -ALLOWS 8050B (R&I) IN ADDITION TO 8050T (SET-UP) AND COMPONENT REPLACEMENT TIME.

DSI BOARD					
R&R	8061A	0.3		X	X
ELECTRODE					
R&R	8057A	0.2		X	X
GAS VALVE					
R&R	8058A	0.4		X	X
LIMIT SWITCH					
R&R	8060A	0.5		X	X
MOTOR					
R&R	8051A	0.6		X	X
ORIFICE (BURNER)					
R&R	8053A	0.2		X	X
RELAY					
R&R	8062A	0.1		X	X
SAIL SWITCH					
R&R	8063A	0.2		X	X

FURNACES

SUBURBAN

IMPORTANT NOTES:

DROP PRESSURE TEST MUST BE PERFORMED UPON COMPLETION OF ANY REPAIRS INVOLVING THE LP GAS SYSTEM. FOLLOW RECOMMENDED SAFETY PROCEDURES AT ALL TIMES.

OPERATIONS ARE FOR THE ACTUAL COMPONENT REPLACEMENT TIMES SUPPLIED BY THE MANUFACTURED. MOST REPAIRS DONOT REQUIRE FURNACE REMOVAL FROM THE UNIT. AN ALLOWANCE OF 0.5 (OPERATION 8070T) MAY BE CLAIMED FOR SET-UP TIME. THIS TIME INCLUDES SET-UP, REMOVING, REINSTALL FURNACE. SET-UP TIME CAN ONLY BE USED ONCE PER REPAIR.

THERMASTAT WALL					
R&R	8065A	0.1		X	X
R&I (NO SET-UP)	8065B	0.1			
SET-UP	8070T	0.5			X
FURNACE R&I	8070B	0.5			X
BLOWER MOTOR					
R&R	8072A	0.4			X
COMBUSTION CHAMBER					
R&R	8073A	1.5			X
ELECTRODE					
R&R	8074A	0.1			X
ELECTRODE WIRE					
R&R	8075A	0.2			X



APPLIANCES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>FURNACES</u>					
SUBURBAN					
IMPORTANT NOTES:					
DROP PRESSURE TEST MUST BE PERFORMED UPON COMPLETION OF ANY REPAIRS INVOLVING THE LP GAS SYSTEM. FOLLOW RECOMMENDED SAFETY PROCEDURES AT ALL TIMES.					
OPERATIONS ARE FOR THE ACTUAL COMPONENT REPLACEMENT TIMES SUPPLIED BY THE MANUFACTURED. MOST REPAIRS <u>DONOT</u> REQUIRE FURNACE REMOVAL FROM THE UNIT. AN ALLOWANCE OF 0.5 (OPERATION 8070T) MAY BE CLAIMED FOR SET-UP TIME. THIS TIME INCLUDES SET-UP, REMOVING, REINSTALL FURNACE. SET-UP TIME CAN ONLY BE USED <u>ONCE</u> PER REPAIR.					
FAN SWITCH					
R&R	8076A	0.2			X
GAS VALVE					
R&R	8077A	0.5		X	X
LIMIT SWITCH					
R&R	8078A	0.2			X
MAIN BURNER					
R&R	8080A	0.5			X
MODULE BOARD					
R&R	8081A	0.2		X	X
POWER CONVERTER					
R&R	8083A	0.3		X	X
RELAY					
R&R	8084A	0.3		X	X
THERMOSTAT					
R&R	8085A	0.1			X
TRANSFORMER					
R&R	8086A	0.5			X
VENT-EXTERIOR					
R&R (NO SET-UP TIME ALLOWED)	8087A	0.2			X
R&I (NO SET-UP TIME ALLOWED)	8087B	0.2			
SEAL (NO SET-UP TIME ALLOWED)	8087S	0.1			
<u>MICROWAVE OVEN</u>					
NOTE: REPAIRS TO THE MICROWAVE, OTHER THAN THOSE LISTED, MUST BE PREFORMED BY A MANUFACTURER'S AUTHORIZED SERVICE CENTER ONLY.					
MICROWAVE					
R&R	8100A	0.5	X	X	X
R&I	8100B	0.3			X
TRIM RING					
R&R	8103A	0.1			
<u>OVEN/RANGE</u>					
WEDGEWOOD/ATWOOD					
OVEN/RANGE					
R&I	8470B	0.6			X
BIFOLD TOP COVER					
R&R	8483A	0.2			X
OVEN BURNER GAS LINE					
R&R	8479A	1.2		X	X



APPLIANCES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>OVEN/RANGE (CONT.)</u>					
<u>WEDGEWOOD/ATWOOD (CONT.)</u>					
BURNER ELECTRODE R&R	8486A	0.3		X	
BURNER GRATE (1-3 GRATES) R&R	8478A	0.1		X	X
BURNER MANIFOLD R&R	8476A	0.5		X	X
OVEN BURNER R&R	8473A	0.3		X	X
OVEN CONTROL R&R	8471A	1.0		X	X
OVEN DOOR R&R	8482A	0.3		X	X
OVEN PILOT GAS LINE R&R	8480A	1.2		X	X
RANGE BURNER R&R	8481A	0.3		X	X
RANGE REGULATOR R&R	8475A	0.5		X	X
RANGE TOP R&R	8477A	0.2			X
SAFTEY CONTROL R&R	8472A	0.5		X	X
TOP BURNER VALVE R&R	8474A	0.6		X	X
PIEZO IGNITER R&R	8484A	0.5		X	X
GRATE GROMMETS R&R (PER TOP)	8485A	0.1			X
<u>RANGE HOOD</u>					
RANGE HOOD R&R	8140A	0.3			
R&I	8140B	0.3			
DAMPER R&R	8144A	0.2			
FAN BLADE R&R	8142A	0.2			
FAN MOTOR R&R	8143A	0.6			
RANGE VENT-EXTERIOR R&R	8146A	0.2			
R&I	8146B	0.2			
SEAL	8146S	0.1			
SWITCH R&R	8145A	0.2			



APPLIANCES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>REFRIGERATORS</u>					
DOMETIC					
REFRIGERATOR					
R&I	8150B	0.5			X
BURNER TUBE					
R&R	8160A	0.5			X
DOOR					
R&R	8163A	0.5			X
DOOR – DECORATIVE PANEL					
R&R	8217A	0.3			X
DOOR GASKET					
R&R	8164A	0.5			X
DOOE HANDLE					
R&R	8175A	0.2			X
ELECTRODE					
R&R	8218A	0.5			X
GAS SHUT-OFF VALVE					
R&R	8179A	0.8			X
HEATING ELEMENT					
R&R	8167A	0.5		X	X
LOWER MODULE (P.C. BOARD)					
R&R	8173A	0.7		X	X
MAIN SWITCH CARD (UPPER P.C. BOARD)					
R&R	8178A	0.5		X	X
ORIFICE					
R&R	8168A	0.7			X
PIEZO IGNITER					
R&R	8169A	1.0		X	X
REIGNITOR					
R&R	8176A	0.5		X	X
RELAY					
R&R	8177A	1.0			X
SAFETY GAS VALVE					
R&R	8170A	1.0		X	X
SOLENOID VALVE					
R&R	8350A	0.5		X	X
MAIN SWITCH					
R&R	8171A	1.0			X
THERMOCOUPLE					
R&R	8172A	0.7		X	X
THERMOSTAT (ELECTRIC)					
R&R	8165A	1.0			X
THERMOSTAT (THERMISTER)					
R&R	8166A	0.5		X	X
DOOR SWITCH					
R&R	8351A	0.5		X	X
CLIMATE CONTROL/LOW AMBIENT SWITCH					
R&R	8352A	0.5		X	X



APPLIANCES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
REFRIGERATORS (CONT.)					
DOMETIC WITH ICE MAKER					
CONDENSER MOTOR					
R&R	8411A	1.0		X	X
CURRENT RELAY					
R&R	8412A	0.8		X	X
FAN BLADE					
R&R	8413A	1.0			X
FILTER/DRYER					
R&R	8414A	2.5		X	X
HARVEST MECHANISM					
R&R	8415A	1.3		X	X
ON/OFF SWITCH					
R&R	8416A	1.0		X	X
WATER SOLENOID VALVE					
R&R	8418A	0.7		X	X
NORCOLD					
REFRIGERATOR ASSEMBLY					
R&I	8158B	0.5			X
BURNER					
R&R	8180A	0.5			X
COOLING UNIT					
R&R	8181A	2.5	X	X	X
COMBINATION CONTROL					
R&R	8213A	1.2		X	X
CONTROL MODULE					
R&R	8182A	0.5		X	X
DOOR (LOWER)					
R&R	8183A	0.3			X
DOOR- DECORATIVE PANEL					
R&R	8217A	0.3			X
DOOR – FREEZER					
R&R	8187A	0.3			X
DOOR GASKET					
R&R	8211A	0.4			X
EYEBROW					
R&R	8184A	0.4			X
EYEBROW PC BOARD					
R&R	8185A	0.5		X	X
SENSOR ELECTRODE					
R&R	8186A	0.5			X
FLAME INDICATOR					
R&R	8214A	0.3			X
GAS VALVE					
R&R	8188A	0.7			X
HEATER					
R&R	8190A	0.6			X
HUMIDITY HEAT STRIP					
R&R	8193A	1.0			X



APPLIANCES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>REFRIGERATORS (CONT.)</u>					
<u>NORCOLD (CONT.)</u>					
HUMIDITY SWITCH R&R	8194A	0.5			X
IGNITION SWITCH R&R	8195A	0.6			X
INTERFACE MODULE R&R	8196A	0.5			X
LIGHT SWITCH R&R	8197A	0.5			X
MANUAL SHUT-OFF R&R	8216A	0.5			X
ORIFICE R&R	8198A	0.5			X
POWER SUPPLY R&R	8199A	0.5		X	X
REGULATOR R&R	8200A	0.5			X
RELIGHTER R&R	8215A	0.5		X	X
ROCKER SWITCH R&R	8201A	0.4			X
SAFETY VALVE R&R	8202A	0.9			X
PIEZO SPARK IGNITER R&R	8203A	0.8			X
THERMISTOR (COMPLETE) R&R	8204A	1.0			X
THERMOCOUPLE R&R	8205A	0.6			X
THERMOSTAT R&R	8206A	1.2			X
THREE WAY SWITCH R&R	8208A	0.6			X
TRAVEL LATCH R&R	8209A	0.3			X
WIRING HARNESS R&R	8210A	1.5			X
<u>REMOTE CONTROL</u>					
REMOTE CONTROL REPLACEMENT	8244A	0.1	X	X	X



APPLIANCES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>TELEVISION</u>					
NOTE: TELEVISIONS ARE <u>NOT</u> WARRANTED BY NEXUS RV AND MUST BE REPAIRED BY A MANUFACTURER'S AUTHORIZED SERVICE CENTER.					
NOTE: THE DEFECTIVE TELEVISION AND ALL PARTS (REMOTE CONTROL, MANUAL, ANTENNA, SPLITTER, CABLES, PACKING MATERIAL) MUST BE RETURNED IN THE REPLACEMENT TELEVISION CARTON.					
NOTE: TELEVISIONS MUST BE RETURNED IN THE PACKING CRATE MATERIAL AND VIA SHIPPING METHOD USED FOR THE REPLACEMENT TV. TELEVISIONS RETURNED VIA UPS AND RECEIVED DAMAGED WILL BE DENIED.					
TELEVISION					
R&R	8240A	0.5	X	X	X
R&I	8240B	0.3			X
TRIM RING					
R&R	8245A	0.2			
R&I	8245B	0.2			
TOUCH-UP	8245X	0.1			
<u>VACUUM CLEANER</u>					
VACUUM CLEANER (CENTRAL)					
R&R	8267A	0.3	X		X
TOOLS (WAND, HOSE, ATTCHMENTS)	8265A	0.1			
VACUUM CLEANER (DIRT DEVIL)					
R&R	8250A	0.1	X	X	X
VACUUM CLEANER (RE-CHARGEABLE)					
R&R	8266A	0.1			
<u>WASHER/DRYER</u>					
R&R	8330A	0.5	X	X	X
R&I	8330B	0.5			X
<u>WATER HEATER</u>					
ATWOOD					
WATER HEATER					
R&I	8270B	0.5			X
REMOVE, SEAL, & REINSTALL	8270D	0.5			
CIRCUIT BOARD					
R&R	8281A	0.5		X	X
CONTROL VALVE (PILOT MODELS)					
R&R	8274A	1.0		X	X
DOOR ACCESS					
R&R	2019A	0.3			X
DOOR (HINGE)					
R&R	8276A	0.1			X
DOOR LATCH					
R&R	8275A	0.1			X
DRAIN VALVE/PLUG					
R&R	8277A	0.3			X
R&I	8277B	0.3			
HEATING ELEMENT					
R&R	8286A	0.3		X	X
INNER TANK (REPLACE WATER HEATER DURING WARRANTY)					
R&R	8280A	2.3	X	X	X



APPLIANCES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>WATER HEATERS (CONT.)</u>					
<u>ATWOOD (CONT.)</u>					
MAIN BURNER					
R&R	8271A	0.5			X
PILOT ASSEMBLY					
R&R	8273A	0.5		X	X
RELIEF VALVE					
R&R	8283A	0.5		X	X
SOLENOID VALVE					
R&R	8279A	0.5		X	X
SPARK & PROBE ASSY					
R&R	8287A	0.5		X	X
SWITCH R&R	8284A	0.5			X
THERMAL CUT OFF					
R&R	8278A	0.3		X	X
THERMOSTAT – 120V					
R&R	8288A	0.5		X	X
THERMOSTAT & ECO					
R&R	8285A	0.5		X	X
<u>SURBURBAN</u>					
WATER HEATER					
R&I	8450B	1.0			
REMOVE, SEAL, REINSTALL	8450D	0.5			
DOOR ASSEMBLY					
R&R	8457A	0.3			X
ECO & THERMOSTAT					
R&R	8460A	0.5		X	X
ELECTRIC THERMOSTAT					
R&R	8459A	0.5		X	X
ELECTRODE					
R&R	8462A	0.5			X
ELEMENT R&R	8458A	0.5		X	X
GAS CONTROL VALVE (ELECTRIC MODELS)					
R&R	8452A	0.5		X	X
GAS CONTROL VALVE (PILOT MODELS)					
R&R	8451A	1.0		X	X
MAIN BURNER					
R&R	8455A	0.5			X
MODULE BOARD					
R&R	8456A	0.5		X	X
ON/OFF LIGHT SWITCH					
R&R	8461A	0.5			X
PRESSURE RELIEF VALVE					
R&R	8454A	0.5		X	X
REIGNITOR					
R&R	8463A	0.2			X
THERMOCOUPLE – PILOT ASSEMBLY					
R&R	8453A	0.5			X



ACCESSORIES

ABOUT THIS SECTION:

ALL LABOR ALLOWANCES INCLUDE ACCESS, DIAGNOSIS, REMOVE AND REINSTALL OF ALL COMPONENTS, SET-UP, AND TESTING UNLESS OTHERWISE NOTED.

MODEL AND SERIAL NUMBER OF COMPONENTS ARE REQUIRED ON THE WARRANTY CLAIM.

COMPONENTS

- AWNINGS
- CO DETECTOR
- FIRE EXTINGUISHER
- FIRE PLACE
- GENERATOR
- LEVELING SYSTEM
- GRILL
- RADIO
- REAR/SIDEVIEW MONITOR SYSTEM
- RUNNING BOARD
- SMOKE DETECTOR
- TV ANTENNA
- COAX CABLE



ACCESSORIES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
-----------	---------------------	------	----------------------	-------------	------------------------------

IMPORTANT NOTES:

MODEL AND SERIAL NUMBER OF HARDWARE OR FABRIC ROLLER TUBE ASSEMBLY ARE REQUIRED ON ALL AWNING CLAIMS.

WHERE A ASTRISK (*) IS INDICATED, PLEASE RETURN ONLY THE DEFECTIVE PORTION OF THE COMPONENT FOR WARRANTY CONSIDERATION.

AWNINGS

A&E

PATIO AWNING

PATIO AWNING COMPLETE

R&R	9250A	1.0	X	X	X
R&I	9250B	0.5			

ADJUSTMENT KNOB

R&R	9263A	0.2			X
-----	-------	-----	--	--	---

CENTER RAFTER

R&R	9261A	0.2			X
-----	-------	-----	--	--	---

CONTROL BOX (ELECTRIC)

R&R	9266A	0.7		X	X
-----	-------	-----	--	---	---

END SUPPORT BRACKET (10,00 DESTINY)

R&R	9251A	0.8			X
-----	-------	-----	--	--	---

FABRIC

*R&R	9252A	0.2	X	X	X
REPOSITION	9252J	0.5			

INNER ARM

R&R	9254A	0.2			X
R&I	9254B	0.2			X

STOP BOLTS (PER AWNING)

ADJUST	9254J	0.2			
--------	-------	-----	--	--	--

LIFT HANDLE

R&R	9262A	0.2			X
-----	-------	-----	--	--	---

MOUNTING BRACKET

R&R	9255A	0.2			X
SEAL	9255S	0.1			

MOTOR

R&R	9268A	0.5		X	X
-----	-------	-----	--	---	---

OUTER ARM

R&R	9256A	0.5			X
R&I	9256B	0.5			X

PULL STRAP

R&R	9264A	0.1			X
-----	-------	-----	--	--	---

REMOTE CONTROL

R&R	9267A	0.3		X	X
-----	-------	-----	--	---	---

SOCKET ASSEMBLY (10.00)

R&R	9257A	1.0			X
-----	-------	-----	--	--	---

TORSION ASSEMBLY

R&R	9258A	0.5			X
ADJUST TENSION	9258J	0.2			X

TORSION ASSEMBLY (ELECTRIC)

R&R	9265A	0.7		X	X
-----	-------	-----	--	---	---



ACCESSORIES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
-----------	---------------------	------	----------------------	-------------	------------------------------

IMPORTANT NOTES:

MODEL AND SERIAL NUMBER OF HARDWARE OR FABRIC ROLLER TUBE ASSEMBLY ARE REQUIRED ON ALL AWNING CLAIMS.

WHERE A ASTRISK (*) IS INDICATED, PLEASE RETURN ONLY THE DEFECTIVE PORTION OF THE COMPONENT FOR WARRANTY CONSIDERATION.

AWNINGS (CONT.)

A&E

PATIO AWNING CONT.

TRAVEL LATCH					
R&R	9259A	0.2			X
TUBE R&R	9260A	2.0	X		X
WIND SENSOR					
R&R	9269A	0.8		X	X
R&I	9269B	0.3			

WINDOW/DOOR AWNING

WINDOW AWNING COMPLETE					
R&R	9270A	0.5	X	X	X
R&R	9270B	0.5			X
FABRIC R&R	9271A	1.0	X	X	X
REPOSITION	9271J	0.3			X
ROLLER COVER					
R&R	9272A	1.0			X
SPRING ASSEMBLY					
R&R	9273A	0.5		X	X
ADJUST TENSION	9273J	0.3			X
TUBE R&R	9274A	1.0	X		X

SLIDE-OUT AWNING

SLIDE OUT AWNING					
R&R (COMPLETE)	9280A	1.0	X	X	X
R&I	9280B	0.5			X
BRACKET – WALL					
R&R	9281A	0.3			X
FABRIC					
*R&R	9282A	1.0	X	X	X
REPOSITION	9282J	0.5			
ROLLER COVER					
R&R	9283A	1.0			X
ROLLER TUBE					
R&R	9284A	1.0	X		X
TORSION ASSEMBLY					
R&R	9285A	0.5			X
ADJUST	9285J	0.3			X



ACCESSORIES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
-----------	---------------------	------	----------------------	-------------	------------------------------

IMPORTANT NOTES:

MODEL AND SERIAL NUMBER OF HARDWARE OR FABRIC ROLLER TUBE ASSEMBLY ARE REQUIRED ON ALL AWNING CLAIMS.

AWNINGS (CONT.)

CAREFREE

PATIO AWNING

PATIO AWNING COMPLETE

R&R	9300A	1.0	X	X	X
R&I	9300B	0.5			X
FABRIC R&R	9301A	1.5	X	X	X
REPOSITION	9301J	0.5			X

HANDLE

R&R	9302A	0.3			X
-----	-------	-----	--	--	---

MAIN ARMS

R&R	9305A	0.3			X
-----	-------	-----	--	--	---

MOUNTING BRACKETS

R&R	9306A	0.3			X
-----	-------	-----	--	--	---

SPRING

R&R	9307A	0.5		X	X
ADJUST	9307J	0.3			X

STORAGE LOCK

R&R	9303A	0.1			X
-----	-------	-----	--	--	---

TUBE R&R	9304A	1.5	X		X
----------	-------	-----	---	--	---

SLIDE-OUT AWNING

SLIDEOUT AWNING

R&R	9310A	1.0	X	X	X
R&I	9310B	0.5			

MOUNTING BRACKETS

R&R	9311A	0.3			X
R&I	9311B	0.3			

FABRIC R&R	9312A	1.0	X	X	X
------------	-------	-----	---	---	---

REPOSITION	9312J	0.5			
------------	-------	-----	--	--	--

SPRING R&R	9314A	0.5		X	X
------------	-------	-----	--	---	---

ADJUST	9314J	0.3			X
--------	-------	-----	--	--	---

TUBE R&R	9313A	1.0	X		X
----------	-------	-----	---	--	---

WIND DEFLECTOR	9315A	0.3			
----------------	-------	-----	--	--	--

CO DETECTOR

CO DETECTOR

R&R	9121A	0.2		X	
R&I	9121B	0.1			

FIRE EXTINGUISHER

R&R	9080A	0.1			
-----	-------	-----	--	--	--

BRACKET/POCKET

R&R	9081A	0.1			
-----	-------	-----	--	--	--

R&I	9081B	0.1			
-----	-------	-----	--	--	--

FIRE PLACE

R&R	9505A	0.1	X	X	
-----	-------	-----	---	---	--



ACCESSORIES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
-----------	---------------------	------	----------------------	-------------	------------------------------

IMPORTANT NOTES:

GENERATORS ARE NOT WARRANTED BY NEXUS RV.

GENERATOR

DASH REMOTE START SWITCH R&R	7100A	0.2		X	
ELECTRIC BOX FOR 110V WIRING R&R	9032A	0.2			
FUEL LINE R&R	9033A	ST			
RELOCATE	9033F	0.3			
REPAIR	9033C	0.2			
HEAVY 12V CABLE R&R	9034A	0.6	X		
RELOCATE	9034F	0.3			
REPAIR	9034C	0.2			
INSULATION (EACH PIECE) R&R	9035A	0.3			
RESECURE	9035R	0.1			
MUFFLER R&R	9038A	0.3			
MUFFLER HANGER R&R	9039A	0.2			
REPAIR	9039C	0.2			
TAIL PIPE R&R	9040A	0.2			
TAIL PIPE HANGER R&R	9041A	0.2			
REPAIR	9041C	0.2			
TRAY R&R	9043C	0.3			
WELD	9043W	0.3			

LEVELING SYSTEM

BIGFOOT

ACTUATOR KIT R&R	9076A	0.6		X	
CONTROL BOX R&R	9075A	0.3		X	
CONTROL PANEL R&R	9060A	0.1		X	
HYDRAULIC HOSE R&R	9064A	0.6		X	
TIGHTEN	9064Y	0.3			
JACK LEG (COMPLETE) R&R	9065A	0.7	X	X	
JACK PRESSURE SWITCH R&R	9077A	0.3		X	
LEVEL SENSOR R&R	9066A	0.3		X	
REPOSITION	9066J	0.3			



ACCESSORIES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>LEVELING SYSTEM (CONT.)</u>					
<u>BIGFOOT</u>					
MANIFOLD PRESSURE SWITCH R&R	9078A	0.2		X	
MOTOR / PUMP ASSEMBLY R&R	9068A	0.5	X	X	
SOLENOID VALVE R&R	9071A	0.2		X	
WARNING SWITCH R&R	9072A	0.3		X	
<u>GRILL</u>					
PORTABLE GRILL R&R	9503A	0.2	X	X	
<u>RADIO</u>					
NOTE: CERTAIN BRANDS REQUIRE REPAIR THRU THE MANUFACTURER'S AUTHORIZED REPRESENTATIVE.					
NOTE: THE DEFECTIVE RADIO AND ALL PARTS (MANUAL, WIRE HARNESS, MOUNTING HARDWARE, FACE PLATES, PACKING MATERIAL, ETC.) MUST BE RETURNED IN THE REPLACEMENT RADIO CARTON.					
RADIO (DASH MOUNT) R&R	7291A	0.5	X	X	X
R&I	7291B	0.5			X
ANTENNA – STATIONARY R&R	7392A	0.4			
CAP SEAL	7292S	0.1			
SPEAKER R&R	7293A	0.2			
SPEAKER COVER R&R	7294A	0.1			
<u>REAR/SIDEVIEW MONITOR SYSTEM</u>					
REAR CAMERA R&R	9090A	0.5	X	X	X
R&I	9090B	0.5	X		X
MONITOR R&R	9091A	0.5	X	X	X
R&I	9091B	0.5	X		X
COAX CABLE R&R	9092A	ST	X		
SIDE CAMERA R&R	9093A	0.5	X	X	X
R&I	9093B	0.5	X		X
<u>RUNNING BOARDS</u>					
MINI HOME RUNNING BOARDS (EACH) R&R	9110A	0.5	X		
<u>SMOKE DETECTOR</u>					
R&R	9120A	0.1		X	



ACCESSORIES

OPERATION	OPERATION NUMBER	TIME	APPROVAL REQUIRED	RETURN PART	MODEL#, SERIAL # REQUIRED
<u>TV ANTENNA</u>					
ANTENNA COMPLETE					
R&R	9150A	1.0	X	X	
R&I	9150B	0.6			
REMOVE, SEAL & REINSTALL	9150D	0.6			
CAP SEAL	9150S	0.1			
ANTENNA HEAD					
R&R	9154A	0.5		X	
BASE PLATE					
R&R	9151A	1.0			
CRANK HANDLE					
R&R	9153A	0.1			
COAX RECEPTACLE (12V NON-BOOSTER)					
R&R	9168A	0.3		X	
COAX RECEPTACLE ONLY					
R&R	9167A	0.2		X	
CABLE SPLITTER					
R&R	9159A	0.2			
COAX CABLE					
R&R	9157A	ST			
LOCATE & REPAIR OPEN/SHORT	9157L	0.3			
COAX CONNECTOR					
R&R	9158A	0.2			
ELEVATING GEAR					
R&R	9152A	0.5			
GEAR HOUSING					
R&R	9148A	1.0		X	
POWER SUPPLY/BOOSTER					
R&R	9156A	0.5		X	
ROTATING HANDLE					
R&R	9149A	0.2			
WORM GEAR					
R&R	9155A	0.5			
<u>COAX CABLE</u>					
COAX CABLE					
R&R	9157A	ST			
LOCATE & REPAIR WIRING	9157L	0.3			
COAX CONNECTOR	9158A	0.2			
CABLE SPLITTER	9159A	0.2			
COAX RECEIPT	9167A	0.2			



FLAT RATE MANUAL TABLE OF CONTENTS

FLATE RATE REVIEW REQUEST	PAGE 2
DEFINITION OF TERMS	PAGE 3 & 4
USING NEXUS FLAT RATE MANUAL	PAGE 5 & 6
PRIOR APPROVAL REQUIRED LIST	PAGE 7 & 8
PARTS REPLACED UNDER NEXUS WARRANTY	PAGE 9
MUST RETURN UNDER NEXUS WARRANTY	PAGE 10-16
SERIAL NUMBER REQUIREMENT LIST	PAGE 17 & 18
CHASSIS & FRAME	PAGE 19-26
EXTERIOR	PAGE 27-42
INTERIOR	PAGE 43-62
SOFT GOODS	PAGE 63-70
WATER SYSTEM	PAGE 71-77
LP GAS SYSTEM	PAGE 78-81
ELECTRICAL	PAGE 82-90
APPLIANCES	PAGE 91-101
ACCESSORIES	PAGE 102-108



FLAT RATE MANUAL INDEX

A

ABS Drain Lines & Components Pg. 72
 Access Door with Frame Pg. 28
 Access Doors pg. 29
 Accordion /Bi- Fold Doors Pg. 52
 A & E Awnings Pg. 103
 Air Conditioners (Roof Mount) Pg. 92
 Antenna's Pg. 108
 Attachments – Exterior Sidewall Pg. 31-33
 Attachments (Roof) Pg. 29-31
 Atwood Furnaces Pg. 93,94
 Atwood Oven/Range Pg. 95
 Atwood Water Heater Pg. 100
 Awnings Pg. 103-105
 Awning Rail Pg. 36

B

Bar Stool Pg. 67
 Base Cabinet Pg. 46
 Bath Lavatory Pg. 45
 Bath (Window) Pg. 39
 Battery (Components) Pg. 83
 Beds Pg. 44,45
 Bedroom (Windows) Pg. 40
 Bedspread Pg. 67
 Bi-Fold / Accordion Door Pg. 52
 Bi-Fold Doors Pg. 74
 Black Water (Holding Tank) Pg. 73
 Bolster/Headboard Pg. 67
 Break Metal Pg. 57
 Bumpers Pg. 20
 Bumper (Fiberglass) Pg. 35
 Bumpers with Stabilizer Jack Pg. 20
 Bus Type Door Pg. 34
 Button Pg. 64

C

Cabinetry Pg. 45-47
 Cabover (Structure) Pg. 38
 Cabover (Windows) Pg. 40
 Cabover Mini (Beds) Pg. 44
 Caps Pg. 35
 Carefree Awnings Pg. 105
 Carpet Pg. 53,54

Ceiling Fan Pg. 83
 Chair (Barrel/Lounge) Pg. 64
 Chair (Dinette/Freestanding) Pg. 64
 Chair (Swivel Rocker) Pg. 64
 Chair (Wall Hugger) Pg. 65
 Circuit Breakers Pg. 83
 Clock Pg. 48
 Closet (Linen/Shirt) Pg. 46
 CO Detector Pg. 105
 Coax Cable Pg. 108
 Cockpit Pg. 40
 Coffee Maker Pg. 92
 Compartment Pg. 33
 Conduit Pg. 83
 Corner Molding Pg. 36
 Countertop Accessories Pg. 48,49
 Countertops Pg. 48
 Curtains/Draperies Pg. 67,68
 Cushion (Cabover) Pg. 65
 Cushion (Dinette) Pg. 65

D

Dash Pg. 50
 Dash A/C -Heater Assembly Pg. 21,22
 Dash/Cockpit Components Pg. 83
 Dash/Cockpit Switches Pg. 88,89
 Decal Pg. 33
 Décor Tape Pg. 33
 Defroster Fan Pg. 83
 Dinette (Cabinet) Pg. 46
 Dinette (Windows) Pg. 40,41
 Diode Pg. 83
 Dometic Refrigerator Pg. 97,98
 Doors Pg. 51,52
 Door/Drawer Hardware Pg. 51,52
 Draperies/Curtains Pg. 67,68
 Drawers Pg. 52
 Driver Door (Frame & Assembly) Pg. 33,34
 Drop Pressure Test Pg. 79
 Ducting Pg. 93
 Duotherm/Dometic Roof A/C Pg. 92

E

Electric Bed Lift Pg. 44
 Electronic Leak Detector Pg. 80
 Engine Cover Pg. 52



FLAT RATE MANUAL INDEX

E

Entertainment Center Cabinet Pg. 46
 Entertainment Center (Outside) Pg. 84
 Entrance Door & Frame Assembly Pg. 33,34
 Entry Door Hand Rail Pg. 53
 Escape Window Pg. 42
 Evans Dash A/C Heater Pg. 21,22
 Exhaust System Pg. 22,23
 Exterior Lights Pg. 84,85
 Exterior Sidewall (Attachments) Pg. 31-33
 Extrusions Pg. 57,58

F

Faucets Pg. 72,73
 Fiberglass/ABS Attachments Pg. 35
 Fire Extinguisher Pg. 105
 Fire Place Pg. 105
 Firewall Pg. 23
 Floor Pg. 53
 Floor (Laminated) Pg. 53,54
 Floor (Non-Laminated) Pg. 53,54
 Floor Coverings Pg. 53,54
 Floor Line Moldings Pg. 37
 Frame Components Pg. 23,24
 Fresh Water (Holding tank) Pg. 73,74
 Fresh Water Pressure Test Pg. 72
 Front Wall (Windows) Pg. 41
 Fuel System Pg. 24
 Furnace (LP Component Supply) Pg. 79
 Furnace Pg. 93,95
 Furniture Pg. 64-67
 Fuse Holder Pg. 84

G

Generator Pg. 106
 Grey Water (Holding Tank) Pg. 74
 Grill Pg. 35,36 & 107

H

Hall (Windows) Pg. 41
 Hardware Pg. 54,55
 Headboard/Bolster Pg. 67
 Headlight Bezel Pg. 35
 Headknocker Pg. 68
 Heat Shield Pg. 23
 Hide-a-bed Pg. 44
 Holding Tanks Pg. 73,74

Hollow Core Door Pg. 51
 Hood Pg. 36
 Horns Pg. 24
 Hoses Pg. 80
 Hydroflame Furnaces Pg. 93,94

I

Interior Cabinet Doors Pg. 51
 Interior Lights Pg. 85,86

J

Junction Box Pg. 84

K

Kitchen Base Cabinetry Pg. 74
 Kitchen (Windows) Pg. 41
 Kitchen Flexible Supply Line Pg. 79

L

Ladder Pg. 29
 Lambrequin (Shadow Box) Pg. 68
 Leveling System Pg. 106,107
 Lights Pg. 84-86
 Lippert Gear Drive System Pg. 60
 Lounge (Window) Pg. 41
 Lower Wall Molding Pg. 37
 LP Component Supply Lines Pg. 79,80
 LP Fittings Pg. 80
 Luggage Rack Pg. 30

M

Manifold (Main Supply) Pg. 80
 Mattress Pg. 68
 Medicine Cabinet Pg. 47
 Microwave Oven Pg. 95
 Microwave Overhead Cabinet Pg. 47
 Mirror Pg. 56
 Moldings Pg. 36-38
 Monitor Panel Pg. 86
 Mud Flap Pg. 25



FLAT RATE MANUAL INDEX

N

Nightstand Cabinet Pg. 47
Norcold Refrigerator Pg. 98,99

O

Outside Shower Pg. 74
Oven/Range Pg. 95,96
Overhead Cabinet Pg. 47

P

Paint Stripe Pg. 38
Painted Bumper Pg. 20
Pantry Cabinet Pg. 47
Pilot Seat Pg. 65,66
Pleated Door Pg. 74
Plumbing Vent Pg. 30
Power Center Pg. 87
Power Inverter Pg. 87

Q

Queen/Double Bed Pg. 44,45

R

Radio Pg. 107
Radio Antenna Pg. 30
Range (LP Component Supply) Pg. 79
Range Hood Pg. 96
Rear/Sideview Monitor System Pg. 107
Rear Wall (Structure) Pg. 39
Rear Wall (Windows) Pg. 41
Receptacles Pg. 87,88
Refrigerators Pg. 97-99
Refrigerator Cabinet Pg. 47
Refrigerator (LP Component Supply) Pg. 79
Regulator Pg. 81
Relays Pg. 88
Remote Control Pg. 99
Roof (attachments) Pg. 29-31
Roof Molding Pg. 37
Roof Vent (Non-powered) Pg. 30
Roof Vent (Powered) Pg. 30
Roof Vent (Refrigerator) Pg. 30
Running Board Pg. 107

S

Screen Clips Pg. 42
Screen (Windows) Pg. 42
Screw Covers (Molding) Pg. 37,38
Seat Belts Pg. 56
Service (Distribution) Panel Pg. 88
Shade Pg. 69
Shelf (Laminated) Pg. 56
Shore Line Cord Pg. 88
Shower Doors Pg. 74
Shower Enclosure (Glass) Pg. 74
Shower Head/Hose Pg. 75
Shower Pan Pg. 75
Shower Seat Pg. 75
Shower Stall (Fiberglass) Pg. 75
Sidewalls Pg. 39
Sinks Pg. 75
Sky light Pg. 31
Slide Out Floor Pg. 56
Slide Out Moldings (Exterior) Pg. 59
Slide Out Room Pg. 56-60
Slide Out Systems Pg. 59,60
Slide Out (Windows) Pg. 41
Slider Window Pg. 42
Sliding Glass Closet Door Pg. 51
Sliding Glass Shower Door Pg. 74
Smoke Detector Pg. 107
Sofa (Hide-A-Bed) Pg. 67
Sofa (Metal Frame Jackknife) Pg. 66
Sofa (Windows) Pg. 41
Solenoid Pg. 88
Speaker Cloth Pg. 69
Spindle Assembly Pg. 60
Spice Rack Pg. 60
Step Base Cabinet Pg. 47
Step Well Pg. 60
Step Entry Door Pg. 38
Structure (Floor, Roof, Walls) Pg. 38,39
Suburban Furnaces Pg. 94
Suburban Water Heater Pg. 101
Switches Pg. 88,89

T

Tables Pg. 61
Tambor Door Pg. 52
Tank Undermount Pg. 81
Television Pg. 100
Termination Valve Pg. 76
Tire & Wheel Pg. 25



FLAT RATE MANUAL INDEX

T

Toilets Pg. 76
Treatments Pg. 67-70
Trim Pads Pg. 70
Trims (Interior) Pg. 61
TV Antenna Pg. 108
TV Cabinet Pg. 47
TV Shelf Pg. 62
Twin Bed Pg. 45

U

Underbelly Material Pg. 39
Up & Angles Pg. 35

V

Vacuum Cleaner Pg. 100
Valance Pg. 69
Venetian Blind Pg. 69
Vertical Blind Pg. 69
Vinyl Flooring Pg. 53

W

Walls Pg. 62
Walls (Laminated) Pg. 62
Washer/Dryer Pg. 100
Water Control Panel Pg. 77
Water Fills Pg. 76,77
Water Heater Pg. 100,101
Water Heater (LP Components Supply) Pg. 80
Water Lines & Fittings Pg. 77
Water Pumps Pg. 77
Wheel Well Pg. 39
Window Components Pg. 42
Windows Pg. 39-41
Windshield Washer & Wiper Pg. 26
Windshields Pg. 42
Wood Plugs Pg. 62

